SUN2000-(50K, 75K, 80K, 150K)-MG Series

User Manual

Issue 11

Date 2025-03-10





Copyright © Huawei Technologies Co., Ltd. 2025. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: https://e.huawei.com

About This Document

Purpose

This document describes the following inverter models (also referred to as SUN2000) in terms of the safety precautions, product introduction, installation, electrical connections, power-on and commissioning, maintenance, and technical specifications. Read this document carefully before installing and operating the inverter.

- SUN2000-150K-MG0-ZH
- SUN2000-150K-MG0
- SUN2000-80K-MGL0
- SUN2000-75K-MGL0-BR
- SUN2000-50K-MGL0-BR
- SUN2000-50K-MGL0

Intended Audience

This document is intended for:

- Technical support engineers
- Hardware installation engineers
- Commissioning engineers
- Maintenance engineers

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
▲ DANGER	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.
<u></u> MARNING	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.

Symbol	Description
⚠ CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.
☐ NOTE	Supplements the important information in the main text. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.

Change History

Changes between document issues are cumulative. The latest document issue contains all the changes made in earlier issues.

Issue 11 (2025-03-10)

Updated **2.3 Appearance**.

Updated 10 Technical Specifications.

Updated 7.4 Commissioning the SUN2000 (Using the App).

Updated A Grid Codes.

Issue 10 (2024-12-13)

Updated A Grid Codes.

Issue 09 (2024-11-20)

Updated 5.5 Connecting DC Input Power Cables.

Issue 08 (2024-08-20)

Updated 1.2 Electrical Safety.

Updated 10 Technical Specifications.

Updated A Grid Codes.

Added C Setting the Current Threshold for Triggering RCD Protection.

Issue 07 (2024-07-15)

Updated the document name.

Updated 2 Overview.

Updated 4.2.1 Site Selection Requirements.

Updated **5.2 Preparing Cables**.

Updated 10 Technical Specifications.

Updated A Grid Codes.

Issue 06 (2024-05-20)

Updated 5.5 Connecting DC Input Power Cables.

Issue 05 (2024-03-20)

Updated 1.3 Environment Requirements.

Updated 2.1 Model.

Updated 2.2 Networking Application.

Updated 2.6 Label Description.

Updated 3 Inverter Storage.

Updated 4.2 Installation Requirements.

Updated 5.6 Connecting Signal Cables.

Updated 8.6 Locating Insulation Resistance Faults.

Updated 10 Technical Specifications.

Updated A Grid Codes.

Added E Baud Rate Negotiation.

Issue 04 (2024-02-02)

Updated 10 Technical Specifications.

Issue 03 (2024-01-12)

Updated 9 Alarm Reference.

Updated 10 Technical Specifications.

Issue 02 (2023-12-12)

Updated 5.4 Connecting an AC Output Power Cable.

Updated 5.5 Connecting DC Input Power Cables.

Updated 9 Alarm Reference.

Issue 01 (2023-11-24)

This issue is used for first office application (FOA).

Contents

About This Document	ii
1 Safety Information	1
1.1 Personal Safety	2
1.2 Electrical Safety	4
1.3 Environment Requirements	7
1.4 Mechanical Safety	g
2 Overview	13
2.1 Model	13
2.2 Networking Application	14
2.2.1 Typical Networking	14
2.2.2 Earthing Systems	17
2.3 Appearance	18
2.4 Circuit Diagram	21
2.5 Working Modes	22
2.6 Label Description	23
2.7 Smart I-V Curve Diagnosis	24
3 Inverter Storage	25
4 Installation	27
4.1 Installation Modes	27
4.2 Installation Requirements	27
4.2.1 Site Selection Requirements	28
4.2.2 Clearance Requirements	29
4.2.3 Angle Requirements	31
4.3 Preparing Tools	32
4.4 Checking Before Installation	34
4.5 Moving the Inverter	35
4.6 Installing the Inverter on a Support	37
4.7 Installing the Inverter on a Wall	
4.8 Installing the SUN2000 on a Pole Clamp	40
5 Electrical Connections	41
5.1 Precautions	41

5.2 Preparing Cables	42
5.3 Connecting a PE Cable	
5.4 Connecting an AC Output Power Cable	
5.5 Connecting DC Input Power Cables	
5.6 Connecting Signal Cables	
5.7 (Optional) Installing the Smart Dongle	
6 Checking Before Power-On	66
7 Power-On and Commissioning	67
7.1 Powering On the Inverter	67
7.2 Commissioning Methods and Process	73
7.3 Commissioning the SUN2000 (Using the SmartLogger)	74
7.3.1 Preparations and SmartLogger WebUI Login	75
7.3.2 Software Upgrade	75
7.3.3 Commissioning Using the Deployment Wizard	75
7.3.4 Parameters Settings	78
7.4 Commissioning the SUN2000 (Using the App)	78
7.4.1 Downloading the FusionSolar App	78
7.4.2 Registering an Installer Account	78
7.4.3 Logging In to or Logging Out of FusionSolar App	
7.4.4 Setup Wizard	79
7.4.5 Commissioning Functions and Features	79
8 System Maintenance	
8.1 Routine Maintenance	
8.2 Shutdown and Power-Off	
8.3 Power-Off for Maintenance	
8.4 Replacing a Fan	
8.5 Resetting and Turning On the DC Switch	
8.6 Locating Insulation Resistance Faults	88
9 Alarm Reference	92
10 Technical Specifications	93
A Grid Codes	99
B Resetting a Password	132
C Setting the Current Threshold for Triggering RCD Protection	133
D Crimping an OT or DT Terminal	135
E Baud Rate Negotiation	138
F Contact Information	140
G Digital Power Customer Service	142

SUN2000-(50K,	75K,	80K,	150K)-MG	Series
User Manual				

Contents

H Acronyms and Abbreviations......143

1 Safety Information

Statement

Before transporting, storing, installing, operating, using, and/or maintaining the equipment, read this document, strictly follow the instructions provided herein, and follow all the safety instructions on the equipment and in this document. In this document, "equipment" refers to the products, software, components, spare parts, and/or services related to this document; "the Company" refers to the manufacturer (producer), seller, and/or service provider of the equipment; "you" refers to the entity that transports, stores, installs, operates, uses, and/or maintains the equipment.

The Danger, Warning, Caution, and Notice statements described in this document do not cover all the safety precautions. You also need to comply with relevant international, national, or regional standards and industry practices. The Company shall not be liable for any consequences that may arise due to violations of safety requirements or safety standards concerning the design, production, and usage of the equipment.

The equipment shall be used in an environment that meets the design specifications. Otherwise, the equipment may be faulty, malfunctioning, or damaged, which is not covered under the warranty. The Company shall not be liable for any property loss, personal injury, or even death caused thereby.

Comply with applicable laws, regulations, standards, and specifications during transportation, storage, installation, operation, use, and maintenance.

Do not perform reverse engineering, decompilation, disassembly, adaptation, implantation, or other derivative operations on the equipment software. Do not study the internal implementation logic of the equipment, obtain the source code of the equipment software, violate intellectual property rights, or disclose any of the performance test results of the equipment software.

The Company shall not be liable for any of the following circumstances or their consequences:

- The equipment is damaged due to force majeure such as earthquakes, floods, volcanic eruptions, debris flows, lightning strikes, fires, wars, armed conflicts, typhoons, hurricanes, tornadoes, and other extreme weather conditions.
- The equipment is operated beyond the conditions specified in this document.

- The equipment is installed or used in environments that do not comply with international, national, or regional standards.
- The equipment is installed or used by unqualified personnel.
- You fail to follow the operation instructions and safety precautions on the product and in the document.
- You remove or modify the product or modify the software code without authorization.
- You or a third party authorized by you cause the equipment damage during transportation.
- The equipment is damaged due to storage conditions that do not meet the requirements specified in the product document.
- You fail to prepare materials and tools that comply with local laws, regulations, and related standards.
- The equipment is damaged due to your or a third party's negligence, intentional breach, gross negligence, or improper operations, or other reasons not related to the Company.

1.1 Personal Safety

⚠ DANGER

Ensure that power is off during installation. Do not install or remove a cable with power on. Transient contact between the core of the cable and the conductor will generate electric arcs or sparks, which may cause a fire or personal injury.

⚠ DANGER

Non-standard and improper operations on the energized equipment may cause fire, electric shocks, or explosion, resulting in property damage, personal injury, or even death.

⚠ DANGER

Before operations, remove conductive objects such as watches, bracelets, bangles, rings, and necklaces to prevent electric shocks.


DANGER

During operations, use dedicated insulated tools to prevent electric shocks or short circuits. The dielectric withstanding voltage level must comply with local laws, regulations, standards, and specifications.

№ WARNING

During operations, wear personal protective equipment such as protective clothing, insulated shoes, goggles, safety helmets, and insulated gloves.

Figure 1-1 Personal protective equipment



General Requirements

- Do not stop protective devices. Pay attention to the warnings, cautions, and related precautionary measures in this document and on the equipment.
- If there is a likelihood of personal injury or equipment damage during operations, immediately stop, report the case to the supervisor, and take feasible protective measures.
- Do not power on the equipment before it is installed or confirmed by professionals.
- Do not touch the power supply equipment directly or with conductors such as damp objects. Before touching any conductor surface or terminal, measure the voltage at the contact point to ensure that there is no risk of electric shock.
- Do not touch operating equipment because the enclosure is hot.
- Do not touch a running fan with your hands, components, screws, tools, or boards. Otherwise, personal injury or equipment damage may occur.
- In the case of a fire, immediately leave the building or the equipment area and activate the fire alarm or call emergency services. Do not enter the affected building or equipment area under any circumstances.

Personnel Requirements

- Only professionals and trained personnel are allowed to operate the equipment.
 - Professionals: personnel who are familiar with the working principles and structure of the equipment, trained or experienced in equipment operations and are clear of the sources and degree of various potential hazards in equipment installation, operation, maintenance

- Trained personnel: personnel who are trained in technology and safety, have required experience, are aware of possible hazards on themselves in certain operations, and are able to take protective measures to minimize the hazards on themselves and other people
- Personnel who plan to install or maintain the equipment must receive adequate training, be able to correctly perform all operations, and understand all necessary safety precautions and local relevant standards.
- Only qualified professionals or trained personnel are allowed to install, operate, and maintain the equipment.
- Only qualified professionals are allowed to remove safety facilities and inspect the equipment.
- Personnel who will perform special tasks such as electrical operations, working at heights, and operations of special equipment must possess the required local qualifications.
- Only authorized professionals are allowed to replace the equipment or components (including software).
- Only personnel who need to work on the equipment are allowed to access the equipment.

1.2 Electrical Safety

DANGER

Before connecting cables, ensure that the equipment is intact. Otherwise, electric shocks or fire may occur.

DANGER

Non-standard and improper operations may result in fire or electric shocks.

DANGER

Prevent foreign matter from entering the equipment during operations. Otherwise, equipment short-circuits or damage, load power derating, power failure, or personal injury may occur.

WARNING

For the equipment that needs to be grounded, install the ground cable first when installing the equipment and remove the ground cable last when removing the equipment.

! WARNING


During the installation of PV strings and the inverter, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the inverter. The resulting device damage is not covered under any warranty.

CAUTION

Do not route cables near the air intake or exhaust vents of the equipment.

General Requirements

- Follow the procedures described in the document for installation, operation, and maintenance. Do not reconstruct or alter the equipment, add components, or change the installation sequence without permission.
- Obtain approval from the national or local electric utility company before connecting the equipment to the grid.
- Observe the power plant safety regulations, such as the operation and work ticket mechanisms.
- Install temporary fences or warning ropes and hang "No Entry" signs around the operation area to keep unauthorized personnel away from the area.
- Before installing or removing power cables, turn off the switches of the equipment and its upstream and downstream switches.
- Before performing operations on the equipment, check that all tools meet the requirements and record the tools. After the operations are complete, collect all of the tools to prevent them from being left inside the equipment.
- Before installing power cables, check that cable labels are correct and cable terminals are insulated.
- When installing the equipment, use a torque tool of a proper measurement range to tighten the screws. When using a wrench to tighten the screws, ensure that the wrench does not tilt and the torque error does not exceed 10% of the specified value.
- Ensure that bolts are tightened with a torque tool and marked in red and blue after double-check. Installation personnel mark tightened bolts in blue.
 Quality inspection personnel confirm that the bolts are tightened and then mark them in red. (The marks must cross the edges of the bolts.)



- If the equipment has multiple inputs, disconnect all the inputs and wait until the equipment is completely powered off before performing operations on the equipment.
- Before maintaining a downstream electrical or power distribution device, turn off the output switch on the power supply equipment.

- During equipment maintenance, attach "Do not switch on" labels near the
 upstream and downstream switches or circuit breakers as well as warning
 signs to prevent accidental connection. The equipment can be powered on
 only after troubleshooting is complete.
- Do not open equipment panels.
- Check equipment connections periodically, ensuring that all screws are securely tightened.
- Only qualified professionals can replace a damaged cable.
- Do not scrawl, damage, or block any labels or nameplates on the equipment. Promptly replace labels that have worn out.
- Do not use solvents such as water, alcohol, or oil to clean electrical components inside or outside of the equipment.
- The surge protection of the PV system and the building where the PV system is installed shall comply with local standards.

Grounding

- Ensure that the grounding impedance of the equipment complies with local electrical standards.
- Ensure that the equipment is connected permanently to the protective ground. Before operating the equipment, check its electrical connection to ensure that it is reliably grounded.
- Do not work on the equipment in the absence of a properly installed ground conductor.
- Do not damage the ground conductor.

Cabling Requirements

- When selecting, installing, and routing cables, follow local safety regulations and rules.
- When routing power cables, ensure that there is no coiling or twisting. Do not join or weld power cables. If necessary, use a longer cable.
- Ensure that all cables are properly connected and insulated, and meet specifications.
- Ensure that the slots and holes for routing cables are free from sharp edges, and that the positions where cables are routed through pipes or cable holes are equipped with cushion materials to prevent the cables from being damaged by sharp edges or burrs.
- Ensure that cables of the same type are bound together neatly and straight and that the cable sheath is intact. When routing cables of different types, ensure that they are away from each other without entanglement and overlapping.
- Secure buried cables using cable supports and cable clips. Ensure that the
 cables in the backfill area are in close contact with the ground to prevent
 cable deformation or damage during backfilling.
- If the external conditions (such as the cable layout or ambient temperature) change, verify the cable usage in accordance with the IEC-60364-5-52 or local laws and regulations. For example, check that the current-carrying capacity meets requirements.

 When routing cables, reserve at least 30 mm clearance between the cables and heat-generating components or areas. This prevents deterioration or damage to the cable insulation layer.

1.3 Environment Requirements

A DANGER

Do not expose the equipment to flammable or explosive gas or smoke. Do not perform any operation on the equipment in such environments.

DANGER

Do not store any flammable or explosive materials in the equipment area.

A DANGER

Do not place the equipment near heat sources or fire sources, such as smoke, candles, heaters, or other heating devices. Overheat may damage the equipment or cause a fire.

MARNING

Install the equipment in an area far away from liquids. Do not install it under areas prone to condensation, such as under water pipes and air exhaust vents, or areas prone to water leakage, such as air conditioner vents, ventilation vents, or feeder windows of the equipment room. Ensure that no liquid enters the equipment to prevent faults or short circuits.

MARNING

To prevent damage or fire due to high temperature, ensure that the ventilation vents or heat dissipation systems are not obstructed or covered by other objects while the equipment is running.

General Requirements

- Store the equipment according to the storage requirements. Equipment damage caused by unqualified storage conditions is not covered under the warranty.
- Keep the installation and operating environments of the equipment within the allowed ranges. Otherwise, its performance and safety will be compromised.

- The operating temperature range provided in the equipment's technical specifications refers to the ambient temperatures in equipment's installation environment.
- Do not install, use, or operate outdoor equipment and cables (including but not limited to moving equipment, operating equipment and cables, inserting connectors to or removing connectors from signal ports connected to outdoor facilities, working at heights, performing outdoor installation, and opening doors) in harsh weather conditions such as lightning, rain, snow, and level 6 or stronger wind.
- Do not install the equipment in an environment with dust, smoke, volatile or corrosive gases, infrared and other radiations, organic solvents, or salty air.
- Do not install the equipment in an environment with conductive metal or magnetic dust.
- Do not install the equipment in an area conducive to the growth of microorganisms such as fungus or mildew.
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference. The equipment shall be installed in an environment with a magnetic field strength less than 4 Gauss. If the magnetic field strength is greater than or equal to 4 Gauss, the equipment may fail to work properly. If the magnetic field strength is high, for example, in a smeltery, you are advised to use a gauss meter to measure the magnetic field strength of the equipment installation position when the smelting equipment is running normally.
- Ensure that the site complies with local laws, regulations, and related standards.
- Ensure that the ground in the installation environment is solid, free from spongy or soft soil, and not prone to subsidence. The site must not be located in a low-lying land prone to water or snow accumulation, and the horizontal level of the site must be above the highest water level of that area in history.
- Do not install the equipment in a position that may be submerged in water.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the equipment outdoors in salt-affected areas because it may be corroded. A salt-affected area refers to the region within 500 m of the coast or prone to sea breeze. Regions prone to sea breeze vary with weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).
- Before opening doors during the installation, operation, and maintenance of the equipment, clean up any water, ice, snow, or other foreign objects on the top of the equipment to prevent foreign objects from falling into the equipment.
- When installing the equipment, ensure that the installation surface is solid enough to bear the weight of the equipment.
- After installing the equipment, remove the packing materials such as cartons, foam, plastics, and cable ties from the equipment area.

1.4 Mechanical Safety

♠ WARNING

Ensure that all necessary tools are ready and inspected by a professional organization. Do not use tools that have signs of scratches or fail to pass the inspection or whose inspection validity period has expired. Ensure that the tools are secure and not overloaded.

↑ WARNING

Do not drill holes into the equipment. Doing so may affect the sealing performance and electromagnetic containment of the equipment and damage components or cables inside. Metal shavings from drilling may short-circuit boards inside the equipment.

General Requirements

- Repaint any paint scratches caused during equipment transportation or installation in a timely manner. Equipment with scratches must not be exposed for an extended period of time.
- Do not perform operations such as arc welding and cutting on the equipment without evaluation by the Company.
- Do not install other devices on the top of the equipment without evaluation by the Company.
- When performing operations over the top of the equipment, take measures to protect the equipment against damage.
- Use correct tools and operate them in the correct way.

Moving Heavy Objects

Be cautious to prevent injury when moving heavy objects.



(< 40 lbs)



18-32 kg (40-70 lbs)



32-55 kg (70-121 lbs)



55-68 kg (121-150 lbs)



(> 150 lbs)

C70000110

- If multiple persons need to move a heavy object together, determine the manpower and work division with consideration of height and other conditions to ensure that the weight is equally distributed.
- If two persons or more move a heavy object together, ensure that the object is lifted and landed simultaneously and moved at a uniform pace under the supervision of one person.

- Wear personal protective gears such as protective gloves and shoes when manually moving the equipment.
- To move an object by hand, approach to the object, squat down, and then lift the object gently and stably by the force of the legs instead of your back. Do not lift it suddenly or turn your body around.
- Do not quickly lift a heavy object above your waist. Place the object on a workbench that is half-waist high or any other appropriate place, adjust the positions of your palms, and then lift it.
- Move a heavy object stably with balanced force at an even and low speed. Put
 down the object stably and slowly to prevent any collision or drop from
 scratching the surface of the equipment or damaging the components and
 cables.
- When moving a heavy object, be aware of the workbench, slope, staircase, and slippery places. When moving a heavy object through a door, ensure that the door is wide enough to move the object and avoid bumping or injury.
- When transferring a heavy object, move your feet instead of turning your waist around. When lifting and transferring a heavy object, ensure that your feet point to the target direction of movement.
- When transporting the equipment using a pallet truck or forklift, ensure that
 the tynes are properly positioned so that the equipment does not topple.
 Before moving the equipment, secure it to the pallet truck or forklift using
 ropes. When moving the equipment, assign dedicated personnel to take care
 of it.
- Choose sea, roads in good conditions, or airplanes for transportation. Do not transport the equipment by railway. Avoid tilt or jolt during transportation.


Using Ladders

- Use wooden or insulated ladders when you need to perform live-line working at heights.
- Platform ladders with protective rails are preferred. Single ladders are not recommended.
- Before using a ladder, check that it is intact and confirm its load bearing capacity. Do not overload it.
- Ensure that the ladder is securely positioned and held firm.




• When climbing up the ladder, keep your body stable and your center of gravity between the side rails, and do not overreach to the sides.

- When a step ladder is used, ensure that the pull ropes are secured.
- If a single ladder is used, the recommended angle for the ladder against the floor is 75 degrees, as shown in the following figure. A square can be used to measure the angle.




- If a single ladder is used, ensure that the wider end of the ladder is at the bottom, and take protective measures to prevent the ladder from sliding.
- If a single ladder is used, do not climb higher than the fourth rung of the ladder from the top.
- If you use a single ladder to climb up to a platform, ensure that the ladder is at least 1 m higher than the platform.



Hoisting

- Only trained and qualified personnel are allowed to perform hoisting operations.
- Install temporary warning signs or fences to isolate the hoisting area.
- Ensure that the foundation where hoisting is performed on meets the load-bearing requirements.
- Before hoisting objects, ensure that hoisting tools are firmly secured onto a fixed object or wall that meets the load-bearing requirements.
- During hoisting, do not stand or walk under the crane or the hoisted objects.
- Do not drag steel ropes and hoisting tools or bump the hoisted objects against hard objects during hoisting.

• Ensure that the angle between two hoisting ropes is no more than 90 degrees, as shown in the following figure.



Drilling Holes

- Obtain consent from the customer and contractor before drilling holes.
- Wear protective equipment such as safety goggles and protective gloves when drilling holes.
- To avoid short circuits or other risks, do not drill holes into buried pipes or cables.
- When drilling holes, protect the equipment from shavings. After drilling, clean up any shavings.

2 Overview

The SUN2000 is a three-phase grid-tied PV string inverter that converts the DC power generated by PV strings into AC power and feeds the power into the power grid.

2.1 Model

This document involves the following product models:

- SUN2000-150K-MG0-ZH
- SUN2000-150K-MG0
- SUN2000-80K-MGL0
- SUN2000-75K-MGL0-BR
- SUN2000-50K-MGL0-BR
- SUN2000-50K-MGL0

□ NOTE

The SUN2000-80K-MGL0, SUN2000-75K-MGL0-BR, SUN2000-50K-MGL0-BR, and SUN2000-50K-MGL0 support only the power grid with the line voltage of 220 V.

Figure 2-1 Model number




Table 2-1 Model description

No.	Meaning	Description
1	Product family identifier	SUN2000: grid-tied solar inverter

No.	Meaning	Description
2	Power level identifier	• 150K: The rated power is 150 kW.
		80K: The rated power is 80 kW.
		75K: The rated power is 75 kW.
		50K: The rated power is 50 kW.
3	Product series identifier	MG0: product series with an input voltage level of 1100 V DC
		 MGL0: product series with an input voltage level of 750 V DC
4	Region identifier	ZH: China Region
		BR: Brazil

2.2 Networking Application

2.2.1 Typical Networking

- All the SUN2000 models support RS485 communication, but only certain models support AC MBUS communication.
- The SUN2000 does not support the access of optimizers.

In the networking diagrams, — indicates the power cable, — indicates the power flow direction, and — indicate the signal flow.

RS485 Networking


NOTICE

- A maximum of 30 SUN2000s can be cascaded to each COM port on the SmartLogger, and a maximum of 10 SUN2000s can be cascaded to the Dongle.
- The RS485 communication distance between the SUN2000 at the end and the SmartLogger must be less than or equal to 1000 m.

(A) PV strings
(B) SUN2000s
(C) AC combiner box
(D) Power meter
(E) Power grid
(F) Management system
(G) SmartLogger

Figure 2-2 RS485 networking application (SmartLogger)

Figure 2-3 RS485 networking application (Dongle)




MBUS Networking

The SUN2000-80K-MGL0, SUN2000-75K-MGL0-BR, SUN2000-50K-MGL0-BR and SUN2000-50K-MGL0 do not support the MBUS function.

NOTICE

- A maximum of 80 SUN2000s can be cascaded to the SmartLogger, and a maximum of 10 SUN2000s can be cascaded to the Dongle.
- If MBUS is used for communication, you are advised to use multi-core cables with the maximum communication distance of 1000 m. To use other types of AC power cables, contact local technical support.

Figure 2-4 MBUS networking application (SmartLogger)






Figure 2-5 MBUS networking application (Dongle)

2.2.2 Earthing Systems

Earthing Systems

The SUN2000 supports the TN-S, TN-C, TN-C-S, TT, and IT earthing systems.


TN-S TN-C TN-C-S L2 L3 L3 Ν PEN PE SUN2000 SUN2000 SUN2000 TT IT L2 L3 PΕ SUN2000 SUN2000 IS12W00005

Figure 2-6 Earthing systems

2.3 Appearance

Appearance and Ports

Figure 2-7 Appearance



- (1) Panel
- (3) Maintenance compartment door
- (5) DC SWITCH 1
- (7) USB port
- (9) DC input terminal group 2 (PV10–PV21, controlled by DC SWITCH 2)
- (11) AC output cable hole

- (2) LED indicators
- (4) Fan tray
- (6) DC input terminal group 1 (PV1–PV9, controlled by DC SWITCH 1)
- (8) RS485 communication port (COM)
- (10) DC SWITCH 2
- (12) Ground point

Indicator Description

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)	Meaning
PV connection indicator	Steady green	At least one PV string is properly connected, and the DC input voltage of the corresponding MPPT circuit is greater than or equal to the minimum startup voltage.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
	Blinking green	fast	If the alarm/maintenance indicator is red, an environmental fault at the DC side of the inverter was generated.
	Off		The inverter is disconnected from all PV strings, or the DC input voltage of all MPPT circuits is less than the minimum startup voltage.
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the DC side of the inverter is generated.
Grid	Steady green		The inverter is in grid-tied mode.
connection indicator	Off Steady red		If the alarm/maintenance indicator is red, an environmental fault on the AC side of the inverter was generated.
			The inverter is not in grid-tied mode.
			If the alarm/maintenance indicator is red, an internal fault on the AC side of the inverter was generated.
Communicati on indicator	Blinking green fast		The inverter receives communication data normally.
((()))	Off		The inverter has not received communication data for 10 seconds.
Alarm/ Maintenance indicator	Alarm	Steady red	 A major alarm was generated. If the PV connection indicator or grid connection indicator is blinking green fast, rectify DC or AC environmental faults as instructed by the SUN2000 app. If neither the PV connection indicator nor the grid connection indicator is blinking green fast, replace components or the inverter as instructed by the SUN2000 app.
		Blinking red fast	A minor alarm was generated.
		Blinking red slowly	A warning alarm was generated.
	Local	Steady green	The local maintenance is successful.
	maintenance	Blinking green fast	The local maintenance failed.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
		Blinking green slowly	The device is under local maintenance or shut down after receiving a command.

□ NOTE

- The PV connection indicator and the grid connection indicator preferentially indicate environmental faults.
- Local maintenance refers to operations performed after a USB flash drive or USB data cable is inserted into the USB port of the inverter. For example, import and export data using a USB flash drive, or connect to the local app using a USB data cable.
- If the alarming and the local maintenance happen concurrently, the alarm/maintenance indicator shows the local maintenance state first. After the USB flash drive or USB data cable is removed, the indicator shows the alarm state.

DC SWITCH


⚠ DANGER

- If both DC switches are automatically turned off at the same time, the AC switch does not trip, and the indicators on the inverter display the following status, do not turn on the DC switches by yourself. Contact your vendor or technical support.
 - 1. LED1, LED2, and LED4 are steady red.
 - 2. LED1 and LED4 are steady red.
- If both DC switches are automatically turned off at the same time, the AC switch does not trip, and the LED4 indicator on the inverter is steady red, do not turn on the DC switches by yourself. Perform operations according to the handling suggestions for alarm ID 2001.
- If all DC switches are automatically turned off at the same time and the AC switch trips, check that no short circuit occurs on the AC side between phases or between a phase and the ground, turn on the AC switch, export logs, and send the logs to your vendor or technical support. Rectify the fault after your vendor or technical support provides a solution. If there is any short circuit on the AC side between phases or between a phase and the ground, do not turn on the AC switch. Contact your vendor or technical support.
- Before turning on a switch, ensure that all alarms have been cleared.
- If the DC switches are automatically turned off and the inverter generates a **String Reverse Connection** or **String Current Backfeed** alarm, rectify the fault based on the alarm handling suggestions. After the fault is rectified, wait for at least 3 minutes, turn the switch handle to **OFF** to complete the reset, and then turn it on. For details, see **Resetting and Turning On the DC SWITCH**.

Table 2-2 DC SWITCH description

Switch	Description	
DC SWITCH	ON	The DC SWITCH is on and can be turned off for protection.
	TRIP	The DC SWITCH is automatically turned off. (The switch handle is between ON and OFF .)
	OFF	The DC SWITCH is off.

Figure 2-8 DC SWITCH
DC SWITCH



2.4 Circuit Diagram

The SUN2000 receives inputs from 21 PV strings. The inputs are grouped into 7 MPPT circuits inside the SUN2000 to track the maximum power point of the PV strings. The DC power is converted into three-phase AC power through an inverter circuit. Surge protection is supported on both the DC and AC sides.

MPPT1 MPPT2 Output EMI filter Input EMI filter 7+ 0-8+ 0-9+ 0-МРРТ3 Output ● PE MPPT4 10- 0 11- 0 12- 0 13+ O-14+ O-15+ O-MPPT5 Input EMI filter Input current check 16+ 0 17+ 0 184 МРРТ6 16-17-18-19+ 0 20+ 0 21+ 0 МРРТ7

Figure 2-9 Circuit diagram

2.5 Working Modes

The SUN2000 can work in Standby, Operating, or Shutdown mode.

Operating mode Shutdown Sufficient power command or fault from PV string Insufficient power detected. and no fault from PV string is detected. or DC switch is turned off. Shutdown Standby Shutdown mode mode command or fault detected. Startup command or fault rectified.

Figure 2-10 Working modes

IS07S00001

Table 2-3 Working mode description

Working Mode	Description
Standby	The SUN2000 enters Standby mode when the external environment does not meet the operating requirements. In Standby mode:
	The SUN2000 continuously performs status check and enters the Operating mode once the operating requirements are met.
	The SUN2000 enters Shutdown mode after detecting a shutdown command or a fault after startup.
Operating	In Operating mode:
	The SUN2000 converts DC power from PV strings into AC power and feeds the power to the power grid.
	The SUN2000 tracks the maximum power point to maximize the PV string output.
	If the SUN2000 detects a fault or a shutdown command, it enters the Shutdown mode.
	The SUN2000 enters Standby mode after detecting that the PV string output power is not suitable for connecting to the power grid for generating power.

Working Mode	Description
Shutdown	In Standby or Operating mode, the SUN2000 enters Shutdown mode after detecting a fault or shutdown command.
	In Shutdown mode, the SUN2000 enters Standby mode after detecting a startup command or that the fault is rectified.

2.6 Label Description

Symbol	Name	Meaning
	Large current warning	Potential hazards exist after the inverter is powered on. Take protective measures when operating the inverter. Before powering on the inverter, ensure that the inverter is grounded because there is a large contact current after the inverter is powered on.
	High temperature hazard	Do not touch the inverter when it is running because its enclosure is hot.
A	Electric shock hazard	Hazardous voltages exist when the inverter is working. Take protective measures during operations and maintenance.
15 mins	Delayed discharge	High voltage exists after the inverter is powered on. Only qualified and trained electrical technicians are allowed to perform operations on the inverter.
		Residual voltage exists after the inverter is powered off. It takes 15 minutes for the inverter to discharge to the safe voltage.
<u>i</u>	Refer to documentation	Reminds operators to refer to the documentation provided with the device. Losses caused by operations that do not comply with the requirements of site selection, storage, or mounting specified in the user manual are not covered under the warranty.

Symbol	Name	Meaning
	Protective earthing	Indicates the position for connecting the protective earthing (PE) cable.
Do not disconnect under load! 禁止带负荷断开连接!	Operation warning	Do not remove the DC input connector when the inverter is running.
Before replacing the fan, disconnect the FAN-POWER cable and then the fan cable. 更换风扇前,必须先拔除风扇电源线,再拔除风扇线。	Fan replacement warning	Before replacing the fan, disconnect its power connector.
(1P)PN/ITEM:XXXXXXXXX (32P)Model:SUN2000-XXKTL-XX (S)SN:XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	Inverter SN	Indicates the inverter serial number.
or or > 55 kg (121 lbs)	Device weight	The inverter needs to be carried by four persons or using a forklift.
MARNING After the DC switch is disconnected automatically, do not turn it on again. Perform operations according to the alarm information and user manual. 政法开关自动分形后,请勿重新拥命,按照合管他示和用户平静进行操作	DC switch operation warning	After a DC switch is automatically turned off, do not directly reset or turn on the DC switch. Instead, follow the instructions in the section "Resetting and Turning On the DC Switch" in the user manual, or contact after-sales service personnel.

2.7 Smart I-V Curve Diagnosis

The SUN2000 supports the Smart I-V Curve Diagnosis. For details, see **iMaster** NetEco V600R023C00 Smart I-V Curve Diagnosis User Manual.

3 Inverter Storage


NOTICE


- Store devices according to the storage requirements. Device damage caused by unqualified storage conditions is not covered under the warranty.
- Do not store the devices without outer packaging.

The following requirements shall be met if inverters are not put into use immediately:

- Do not remove the outer packaging. Check the packaging regularly (recommended: once every three months). Replace any packaging that is damaged during storage.
- If an inverter is unpacked but will not be used immediately, put it back to the original packaging with the desiccant, and seal it with tape.
- Inverters must be stored in a clean and dry environment with appropriate temperature and humidity. The air must not contain corrosive or flammable gases.

Figure 3-1 Storage temperature and humidity






IS07W00011

- When temporarily storing inverters outdoors, do not stack them on a pallet. Take rainproof measures such as using tarpaulins to protect inverters from rain and water.
- Do not tilt a packing case or place it upside down.
- To avoid personal injury or device damage, stack inverters with caution to prevent them from falling over.

Figure 3-2 Maximum number of stacking layers (In the figure, N indicates the maximum number of stacking layers.)



- Do not store inverters for more than two years. If inverters have been stored for two years or longer, they must be checked and tested by professionals before being put into use.
- If an inverter has not been running for six months or longer after being mounted, it may have failed and must be checked and tested by professionals before being put into operation.

4 Installation

4.1 Installation Modes

The inverter can be mounted on a wall, support, or pole clamp.

Table 4-1 Installation modes

Installation Mode	Screw Specifications	Description
Wall mounting	M12x60 stainless steel expansion anchor bolt	Prepared by the customer
Support mounting	M12x40 bolt assembly	Delivered with the mounting bracket. If the length does not meet the installation requirements, the customer shall prepare M12 bolt assemblies and install them together with the M12 nuts delivered with the product.
Pole-clamp mounting	Depending on the pole clamp	Prepared by the customer

4.2 Installation Requirements

4.2.1 Site Selection Requirements

Installation Environment Requirements

- Keep the inverter out of reach of children.
- Do not install the inverter in working or living areas to avoid personal injury or property loss caused by accidental contact by non-professionals or other reasons during device operation.
- Do not install the inverter in noise-sensitive areas (such as residential areas, office areas, and schools) to avoid complaints. If the preceding areas are unavoidable, the distance between the installation position and noise-sensitive areas must be greater than 40 m. Alternatively, use other low-noise models.
- If the device is installed in public places (such as parking lots, stations, and factories) other than working and living areas, install a protective net outside the device and set up a safety warning sign to isolate the device. This is to avoid personal injury or property loss caused by accidental contact by non-professionals or other reasons during device operation.
- If the equipment is installed in a place with abundant vegetation, in addition to routine weeding, harden the ground underneath the equipment using cement or gravel (the area shall be greater than or equal to 3 m x 2.5 m).
- Do not install the equipment in an area with strong vibration, noise, or electromagnetic interference. The equipment shall be installed in an environment with a magnetic field strength less than 4 Gauss. If the magnetic field strength is greater than or equal to 4 Gauss, the equipment may fail to work properly. If the magnetic field strength is high, for example, in a smeltery, you are advised to use a gauss meter to measure the magnetic field strength of the equipment installation position when the smelting equipment is running normally.
- Do not install the inverter in areas containing flammable materials (such as sulfur, phosphorus, liquefied petroleum gas, marsh gas, flour, and cotton) to avoid personal injury or property loss caused by fire or other reasons.
- Do not install the inverter in areas containing explosives (such as blasting agents, display shells, fireworks, and firecrackers) to avoid personal injury or property loss caused by explosion or other reasons.
- Do not install the inverter in areas with corrosive substances (such as sulfuric acid, hydrochloric acid, nitric acid, hydrogen sulfide, and chlorine) to avoid inverter failure caused by corrosion, which is not covered under the warranty.
- Do not install the inverter where its enclosure and heat sink are easily accessible, because the voltage is high and these parts are hot during operation.
- The inverter provides self-protection in high-temperature environments. Its energy yield may decrease as the ambient temperature increases. Ensure that the following installation requirements are met:
 - Install the inverter in a well-ventilated environment to ensure good heat dissipation.
 - If the inverter is installed in an enclosed environment, the heat dissipation equipment or ventilation equipment shall be installed. The indoor ambient temperature must not be higher than the outdoor ambient temperature.

- You are advised to install the device in a sheltered place or install an awning over it to avoid direct sunlight.
- Reserve sufficient clearance around the inverter for installation and heat dissipation.
- The inverter will become corroded if installed in areas exposed to salt. Before installing the inverter outdoors in such areas, consult with the Company. A salt-affected area refers to the region within 500 m of the coast or prone to sea breeze. Regions prone to sea breeze vary with weather conditions (such as typhoons and monsoons) or terrains (such as dams and hills).



The SUN2000-50K-MGL0-BR and SUN2000-75K-MGL0-BR shall be installed in compliance with the technical standards for PV electrical installation (NBR 16690) and the technical standards for PV system fire risk management (IEC 63226).


Mounting Structure Requirements

- The mounting structure for the inverter must be fireproof. Do not install the inverter on flammable building materials to avoid personal injury or property loss caused by fire or other reasons.
- Ensure that the installation surface is solid enough to bear the weight of the inverter to avoid personal injury or property loss caused by the collapse of the mounting structure or other reasons.
- In residential areas, do not install the inverter on plaster board walls or walls made of similar materials with a weak sound insulation performance because the noise generated by the inverter may interfere with residents.

4.2.2 Clearance Requirements

Dimensions


Figure 4-1 Dimensions



Installation Clearance Requirements

Reserve sufficient clearance around the SUN2000 for installation and heat dissipation.

Figure 4-2 Clearance



Ⅲ NOTE

For ease of the SUN2000 installation on the mounting bracket, cable connecting at the bottom, and future maintenance, it is recommended that the clearance from the bottom be between 600 mm and 730 mm. For further questions regarding clearance, consult local technical support engineers.

When installing multiple SUN2000s, install them in horizontal mode if sufficient space is available and install them in triangle mode if no sufficient space is available. Stacked installation is not recommended.

Figure 4-3 Horizontal installation mode (recommended)






Figure 4-4 Triangle installation mode (recommended)



≥ 200 mm

Figure 4-5 Back-to-back installation mode (recommended)

Figure 4-6 Stacked installation mode (not recommended)




4.2.3 Angle Requirements

The inverter can be support-mounted or wall-mounted. The installation angle requirements are as follows:

- Install the inverter vertically or at a maximum back tilt of 75 degrees to facilitate heat dissipation.
- Do not install the inverter at forward tilted, excessive back tilted, side tilted, horizontal, or upside down positions.

Figure 4-7 Installation angle



4.3 Preparing Tools

Category	Tool			
Installation	Hammer drill	Drill bit (Φ14 mm and Φ16 mm)	Insulated torque socket wrench (including an extension bar ≥ 50 mm)	Phillips insulated torque screwdriver

Category	Tool			
	Flat-head insulated torque screwdriver	Wire stripper	Diagonal pliers	Rubber mallet
	000000			0.103
	Utility knife	Cable cutter	Crimping tool H4STC0001 (AMPHENOL) or CT75A-FJB10 (AVIC JONHON)	Spanner H4TW0001 (AMPHENOL) or CT75A-FJB7 (AVIC JONHON)
	RJ45 crimping tool	Vacuum cleaner	Multimeter (DC voltage measurement range ≥ 1100 V DC)	Marker
		<u> </u>		
	Steel measuring tape	Level	Hydraulic pliers	Heat shrink tubing

Category	Tool			
		0		
	Heat gun	Cable tie	Scissors	Insulation resistance tester (output voltage > 1500 V)
Daysanal				
Personal protective	Insulated gloves	Goggles	Dust mask	Insulated shoes
equipment (PPE)			Carlin San	-
	Safety helmet	Reflective vest	Protective gloves	

4.4 Checking Before Installation

Outer Packing Materials

Before unpacking the inverter, check the outer packing materials for damage, such as holes and cracks, and check the inverter model. If any damage is found or the inverter model is not what you requested, do not unpack the package and contact your supplier as soon as possible.

□ NOTE

You are advised to remove the packing materials within 24 hours before installing the inverter.

Package Contents

NOTICE

• After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.

After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

∩ NOTE

For details about the number of contents, see the *Packing List* in the packing case.

4.5 Moving the Inverter


Procedure

Step 1 Take the inverter out of the packing case and move it to the installation position.

NOTICE


- After placing the equipment in the installation position, unpack it with care to prevent scratches. Keep the equipment stable during unpacking.
- Handles are packed in a fitting bag and are not delivered with the inverter.
- Secure the lifting handles (with the steel washers of the lifting handles closely fitted to the inverter).
- If the stud of a lifting handle is bent, replace the lifting handle in time.
- Four persons or appropriate transportation tools are required to move the inverter.
- Do not use the ports or wiring terminals at the bottom to support any weight of the inverter.
- When you need to temporally place the inverter on the ground, use foam, cardboard, or other protection material to prevent damage to its enclosure.
- To avoid damage to the inverter, do not lift or hoist it with an improper hold as shown in Figure 4-9.

Figure 4-8 Taking out, moving, or mounting the inverter



- (A) Taking out the inverter
- (B) Installing the lifting (C) Moving the handles inverter
- (D) Mounting the inverter


Figure 4-9 Lifting positions



◯ NOTE

If the installation position is high, you can hoist the inverter.

Figure 4-10 Hoisting




----End

4.6 Installing the Inverter on a Support

Procedure

Step 1 Remove the torx key and store it properly.

Figure 4-11 Removing the torx key




Step 2 Secure the mounting bracket.

□ NOTE

- The mounting bracket of the inverter has four groups of tapped holes, each group containing four tapped holes. Mark any hole in each group based on site requirements and mark four holes in total. The two round holes are recommended.
- M12x40 bolt assemblies are delivered with the inverter and bound to the mounting bracket. If the bolt length does not meet the installation requirements, prepare M12 bolt assemblies by yourself and use them together with the delivered M12 nuts.

Figure 4-12 Installing the mounting bracket



Step 3 Secure the inverter.

----End

Figure 4-13 Securing the inverter

4.7 Installing the Inverter on a Wall

Procedure

- **Step 1** Determine the hole positions and mark them using a marker.
- **Step 2** Secure the mounting bracket.



Avoid drilling holes into the water pipes or power cables buried in the wall.

Figure 4-14 Expansion bolt structure



IS05W00018

(1) Bolt


(2) Nut

(3) Spring washer

- (4) Flat washer
- (5) Expansion sleeve

- To prevent dust inhalation or contact with eyes, wear safety goggles and a dust mask when drilling holes.
- Use a vacuum cleaner to clean up dust in and around the holes, and measure the spacing. If the holes are inaccurately positioned, drill the holes again.
- Level the top of the expansion sleeve with the concrete wall after removing the nut, spring washer, and flat washer. Otherwise, the mounting bracket will not be securely installed on the concrete wall.


Figure 4-15 Installing an expansion bolt



Step 3 Secure the inverter.


----End

Figure 4-16 Securing the inverter



4.8 Installing the SUN2000 on a Pole Clamp

Figure 4-17 Pole-clamp installation



5 Electrical Connections

5.1 Precautions

⚠ DANGER

- When exposed to sunlight, the PV arrays supply DC voltage to the inverter.
 Before connecting cables, ensure that each DC SWITCH on the inverter is set to OFF. Otherwise, the high voltage of the inverter may result in electric shocks.
- The site must be equipped with qualified fire fighting facilities, such as fire sand and carbon dioxide fire extinguishers.
- Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

MARNING

- The equipment damage caused by incorrect cable connections is beyond the warranty scope.
- Only certified electrician can perform electrical terminations.
- Operation personnel must wear PPE when connecting cables.
- Before connecting cables to ports, leave enough slack to reduce the tension on the cables and prevent poor cable connections.

A CAUTION

• Stay away from the equipment when preparing cables to prevent cable scraps from entering the equipment. Cable scraps may cause sparks and result in personal injury and equipment damage.

□ NOTE

The cable colors shown in the electrical connection diagrams provided in this section are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for protective earthing).

5.2 Preparing Cables

Figure 5-1 Cable connections (configure the components in the dotted box as required)




Table 5-1 Component description

No.	Component	Description	Source
A	PV string	 A PV string consists of PV modules connected in series. The inverter supports 21 PV string inputs. 	Prepared by the customer
В	SmartLogger	The SUN2000 communicates with the management system through the SmartLogger.	Purchased from the Company
С	SUN2000	Select a proper model as required.	Purchased from the Company
D	Power meter ^[1]	Implements power control at the grid connection point in low voltage scenarios using a power meter.	Purchased from the Company
		Recommended power meter models: DTSU666-HW, YDS60-80, DHSU1079- ZT, and DTSU71C	

No.	Component	Description	Source
E	AC switch	To ensure that the inverter can be safely disconnected from the power grid when an exception occurs, connect an AC switch to the AC side of the inverter. Select an appropriate AC switch in accordance with local industry standards and regulations. Installed in the AC combiner box A three-phase AC circuit breaker is recommended. For the model	Prepared by the customer
		information, see Table 5-2 .	
F	Dongle	The SUN2000 communicates with the management system through the Dongle.	Purchased from the Company

Note [1]: For details about how to operate the power meter, see DTSU666-HW Smart Power Sensor Quick Guide, YDS60-80 Smart Power Sensor Quick Guide, DHSU1079-ZT Smart Power Sensor Quick Guide, or DTSU71C Smart Power Sensor Quick Guide.

Table 5-2 Specifications of the three-phase AC circuit breaker

Rated Voltage	Rated Current	Applicable Inverter Model
≥ 500 V AC	315 A	SUN2000-150K-MG0/ SUN2000-150K-MG0-ZH
240 V AC/400 V AC	250 A	SUN2000-80K-MGL0/ SUN2000-75K-MGL0-BR
240 V AC/400 V AC	160 A	SUN2000-50K-MGL0/ SUN2000-50K-MGL0-BR

NOTICE

The inverter has an internal residual current monitoring unit (RCMU). Its external AC switch should be a three-phase circuit breaker or any other AC load circuit breaker to safely disconnect the inverter from the power grid.

■ NOTE

- Select cables in compliance with local cable standards.
- The factors that affect cable selection include the rated current, cable type, routing mode, ambient temperature, and maximum expected line loss.

Table 5-3 Cable description (S indicates the conductor cross-sectional area of the AC cable, and S_p indicates the conductor cross-sectional area of the PE cable)

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
1	PE cable ^[1]	Single-core outdoor copper cable and M10 OT/DT terminal	S _p ≥ S/2	-	Prepared by the customer
2	DC input power cable	PV cable that meets the 1100 V standard	4–6 mm ²	5.5–9 mm	Prepared by the customer

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
3	AC output power cable (multi-core)	 If you connect a PE cable to the ground point on the enclosure and no neutral wire is used, you are advised to use a three-core (L1, L2, and L3) outdoor cable and M12 OT/DT terminals (L1, L2, and L3). If you connect a PE cable to the ground point in the maintenance compartment and no neutral wire is used, you are advised to use a four-core (L1, L2, L3, and PE) outdoor cable, M12 OT/DT terminals (L1, L2, and L3), and M10 OT/DT terminals (PE). If you connect a PE cable to the ground point on the enclosure and a neutral wire is used, you are advised to use a four-core (L1, L2, L3, and N) outdoor cable and M12 OT/DT terminals (L1, L2, L3, and N). If you connect a PE cable to the ground point in the maintenance compartment and a neutral wire is used, you are advised to use a five-core (L1, L2, L3, and N). If you connect a PE cable to the ground point in the maintenance compartment and a neutral wire is used, you are advised to use a five-core (L1, L2, L3, and N). If you connect a PE cable to the ground point in the maintenance compartment and a neutral wire is used, you are advised to use a five-core (L1, L2, L3, and N), and M10 OT/DT terminals (L1, L2, L3, and N), and M10 OT/DT terminals (PE). 	 S: 95-240 mm² S_p ≥ S/2 	24-66 mm	Prepared by the customer

No.	Cable	Туре	Conductor Cross-Sectional Area	Outer Diameter	Source
	AC output power cable (single-core)	(Recommended) Single- core outdoor cable and M12 OT/DT terminal	 S: 95-400 mm² S_p ≥ S/2 	14–38 mm	Prepared by the customer
4	RS485 communicatio ns cable	Outdoor shielded twisted pair cable that meets the local standard	0.25–1 mm ²	 One or two communic ations cables: 4–11 mm Three communic ations cables: 4–8 mm 	Prepared by the customer

Note [1]: The S_p value is valid only if the conductors of the PE cable and AC output power cable use the same material. If the materials are different, ensure that the conductor cross-sectional area of the PE cable produces a conductance equivalent to that specified in this table. The specifications of the PE cable are subject to this table or calculated according to IEC 60364-5-54.

5.3 Connecting a PE Cable

Precautions

A DANGER

- Ensure that the PE cable is securely connected. Otherwise, electric shocks may occur.
- Do not connect the neutral wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.


- Proper grounding is helpful for resisting the impact of surge voltage and improving the electromagnetic interference (EMI) performance. Before connecting the AC power cable, DC power cables, and communications cable, connect the PE cable to the PE point.
- You are advised to connect the PE cable to the PE point on the enclosure. The
 PE point in the maintenance compartment is used for connecting to the PE wire
 of a multi-core AC power cable. If the cross-sectional area of the PE cable
 meets the requirements, select either PE point on the enclosure or in the
 maintenance compartment for connecting the PE cable.
- It is recommended that the inverter be connected to a nearby PE point.

 Connect the PE points of all inverters in the same array to ensure equipotential connections to PE cables.

Procedure

Step 1 Connect the PE cable to the PE point. To enhance the corrosion resistance of a PE terminal, apply silicone grease or paint on it after connecting the PE cable to the PE point on the enclosure.

Figure 5-2 Connecting a PE cable to the PE point (on the enclosure)



----End

5.4 Connecting an AC Output Power Cable

Precautions

- A three-phase AC switch should be installed on the AC side of the inverter. To
 ensure that the inverter can safely disconnect itself from the power grid when
 an exception occurs, select a proper overcurrent protection device in
 compliance with local power distribution regulations.
- The inverter is integrated with a comprehensive residual current detection unit to distinguish fault current from residual current. Upon detecting that the residual current exceeds the threshold, the inverter immediately disconnects from the power grid.

MARNING

- Do not connect loads between an inverter and an AC switch that directly connects to the inverter. Otherwise, the switch may trip by mistake.
- If an AC switch is used with specifications beyond local standards, regulations, or the Company's recommendations, the switch may fail to turn off in a timely manner in case of exceptions, causing serious faults.
- Do not open the panel of the inverter.
- Before opening the maintenance compartment door, ensure that no electrical connections are made for the inverter on the AC or DC side.
- Do not open the maintenance compartment door on rainy or snowy days. If you need to, take protective measures to prevent rain or snow from entering the maintenance compartment. If protective measures cannot be taken, do not open the maintenance compartment door.
- Do not leave unused screws in the maintenance compartment.

⚠ CAUTION

Each inverter shall be equipped with an AC output switch. Multiple inverters shall not connect to the same AC switch.

CAUTION

Cables must be vertically routed into the maintenance compartment, PV terminals, and other wiring terminals to avoid damage caused by horizontal stress on the terminals, which is not covered under the warranty.

NOTICE


- The cable outer diameter can be measured using the ruler sticker in the maintenance compartment.
- Ensure that the cable jacket is in the maintenance compartment.
- If you remove too many parts of the rubber ring of a cable, making the cable hole diameter greater than the cable outer diameter, use firestop putty to seal the gap around the rubber ring of the cable.
- Ensure that the AC output power cables are connected securely. Otherwise, the
 inverter may fail to operate, or become overheated during operation due to an
 unreliable connection, which will damage the terminal block. The resulting
 device damage is not covered under any warranty.
- You are advised to connect the PE cable to the PE point on the enclosure. The
 PE point in the maintenance compartment is used for connecting to the PE wire
 of a multi-core AC power cable. If the cross-sectional area of the PE cable
 meets the requirements, select either PE point on the enclosure or in the
 maintenance compartment for connecting the PE cable.

Picture Single-core Cable Multi-core Cable Unarmored Unarmored Armored Armored R ≥ 20D R ≥ 15D R ≥ 15D R ≥ 12D R indicates the bending radius, and D indicates the outer diameter of the cable. The AC power cable must be routed vertically into the maintenance compartment. IS18W00015

Table 5-4 Bending radius requirements for AC power cables

Wiring Area


Figure 5-3 Wiring ports



Procedure

Step 1 Open the maintenance compartment door and install the door stopper.

Figure 5-4 Opening a maintenance compartment door



Step 2 Connect the AC output power cables based on the cable type.

Figure 5-5 Specifications of the crimped OT/DT terminal





Figure 5-6 Cable connection



- (A) Single-core cable
- (B) Four-core cable (including (C) Five-core cable the neutral wire)

- (D) Three-core cable
- (E) Four-core cable (including the PE wire)

- Reserve sufficient slack for the PE wire to ensure that the PE wire is the last cable bearing the force when the AC output power cable is subject to a pulling force due to force majeure.
- After cables are connected, prevent them from contacting the inter-phase baffle plates.

D: 14-16 mm

D: 16-22 mm

D: 22-28 mm

D: 28-38 mm

Figure 5-7 Single-core cable connection

NOTICE

If a multi-core cable is used, it is recommended that the stripping length of the L2 wire be 15 mm shorter than those of the L1 and L3 wires.




Figure 5-8 Multi-core cable connection (using a five-core cable as an example)

Step 3 Clear foreign matter from the maintenance compartment, close the maintenance compartment door, and check that the cable holes at the bottom of the maintenance compartment are sealed.

Figure 5-9 Closing a door

M6

S N·m

----End

5.5 Connecting DC Input Power Cables

Precautions

DANGER

- Before connecting the DC input power cables, ensure that the DC voltage is within the safety voltage range (lower than 60 V DC) and that each DC
 SWITCH of the inverter is OFF. Otherwise, the high voltage may result in electric shocks.
- When the inverter operates in grid-tied mode, do not perform maintenance or operations on the DC input power cables, such as connecting or disconnecting a PV string or a PV module in the PV string. Otherwise, electric shocks or arcing (which may cause fire) may occur.
- For details about how to remove and insert DC input connectors, see 8.3
 Power-Off for Maintenance.

MARNING

Ensure that the following conditions are met. Otherwise, the inverter may be damaged or even a fire may occur.

- According to IEC 62548, the maximum open-circuit voltage of each PV string cannot exceed 1100 V DC at the lowest average annual dry-bulb temperature.
- The polarities of electric connections must be correct on the DC input side. The
 positive and negative terminals of a PV string must be connected to
 corresponding positive and negative DC input terminals of the inverter.

MARNING

During the installation of PV strings and the inverter, the positive or negative terminals of PV strings may be short-circuited to ground if the power cables are not properly installed or routed. In this case, an AC or DC short circuit may occur and damage the inverter. The resulting device damage is not covered under any warranty.

CAUTION

Take waterproof and insulation measures for unused DC power cables to avoid personal injury or property loss caused by accidental contact with high voltage or other reasons.

- Ensure that the PV module output is well insulated to ground.
- All PV strings connecting to the same MPPT circuit shall consist of the same quantity of PV modules of the same model.
- To ensure the optimal power generation of the system, the voltage difference between different MPPT circuits shall be less than 126 V.

Terminal Description

The inverter provides 21 DC input terminals, which are controlled by its two DC switches: DC SWITCH 1 controls the DC input terminals PV1–PV9 and DC SWITCH 2 controls the DC input terminals PV10–PV21.

Figure 5-10 DC terminals controlled by DC SWITCH 1





Figure 5-11 DC terminals controlled by DC SWITCH 2



If the DC input terminals are not fully configured with PV strings, evenly distribute the DC input PV strings on each MPPT. For 8 to 20 PV strings, the following DC input terminals are recommended.

- For more than 7 PV strings, all MPPT circuits must have PV strings connected.
- Connect the third PV string to an MPPT circuit only after each MPPT circuit has been connected to two PV strings.
- The newly added PV strings shall be connected to MPPT1 and MPPT7 preferentially.
- The quantities of PV strings under DC SWITCH 1 and DC SWITCH 2 shall be the same if possible.

Quanti ty of PV Strings	Terminal Selection	Quanti ty of PV Strings	Terminal Selection
8	PV1/3/4/9/10/13/18/21	9	PV1/3/4/9/10/13/18/19/21
10	PV1/3/4/6/9/10/13/18/19/21	11	PV1/3/4/6/9/10/13/16/18/19/21
12	PV1/3/4/6/8/9/10/13/16/18/19/21	13	PV1/3/4/6/8/9/10/13/15/16/18/19/21
14	PV1/3/4/6/8/9/10/12/13/15/16/18/19/21	15	PV1/2/3/4/6/8/9/10/12/13/15/16/18/ 19/21

Quanti ty of PV Strings	Terminal Selection	Quanti ty of PV Strings	Terminal Selection
16	PV1/2/3/4/6/8/9/10/12/13/15/16/18/ 19/20/21	17	PV1/2/3/4/5/6/8/9/10/12/13/15/16/1 8/19/20/21
18	PV1/2/3/4/5/6/8/9/10/12/13/15/16/1 7/18/19/20/21	19	PV1/2/3/4/5/6/8/9/10/12/13/14/15/1 6/17/18/19/20/21
			□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □
20	PV1/2/3/4/5/6/7/8/9/10/12/13/14/15/ 16/17/18/19/20/21	-	-

Procedure

NOTICE

- Use the PV connectors delivered with the inverter. If the PV connectors are lost or damaged, purchase the connectors of the same model. The device damage caused by incompatible PV connectors is not covered under any warranty.
- Connect the connectors on the PV strings to the connectors on the inverter, and pull back the connectors on the PV strings along the axial direction to check whether the connectors are securely installed.
- Ensure that the connectors are properly connected. Any connector damage due to improper connection is not covered under any warranty.

□ NOTE


The multimeter must have a DC voltage range of at least 1100 V. If the voltage is a negative value, the DC input polarity is incorrect. Rectify the connection. If the voltage is greater than 1100 V, too many PV modules are connected to the same string. Remove some PV modules.

Step 1 Before connecting PV strings to the inverter, ensure that the insulation resistance of each PV string to the ground is normal.

Test method: Use an insulation resistance tester to test the insulation resistance of the PV- cable to the ground. Add a DC voltage of more than 1000 V between the PV- cable and the ground and check the insulation resistance.

- If the insulation resistance is greater than or equal to 1 M Ω , the insulation resistance is normal.
- If the insulation resistance is less than 1 M Ω , troubleshoot the insulation fault of the cable or PV string.

Figure 5-12 Testing the insulation resistance



□ NOTE

You can prepare a tool to connect all PV- cables together using a conversion adapter and measure the ground insulation resistance of all PV- cables of an inverter at a time.


PV1PV2PV2PVnPVnIS12N00001


Figure 5-13 Measuring the insulation resistance of all PV- cables

Step 2 Connect DC input power cables.

When installing DC input power cables, leave at least 150 mm of slack. The axial tension on PV connectors must not exceed 80 N. Radial stress or torque must not be generated on PV connectors.

Figure 5-14 DC input power cabling requirement








Figure 5-15 Connecting DC input power cables (AVIC JONHON)

Inverter Model

SUN2000-150K-MG0-ZH




Figure 5-16 Connecting DC input power cables (Amphenol)

Step 3 Use sealing plugs with snap-fits to seal the DC input terminals that are not connected to PV strings. Device damage caused by the absence of sealing plugs is not covered by warranty.

SUN2000-50K-MGL0

Figure 5-17 Sealing plugs with snap-fits



SUN2000-150K-MG0-ZH

SUN2000-150K-MG0

SUN2000-80K-MGL0

SUN2000-75K-MGL0-BR

SUN2000-50K-MGL0-BR

SUN2000-50K-MGL0

----End

Sealing plug+/Sealing plug-: CT75A-FJB6/ CT75A-FJB5

Sealing plug+/Sealing plug-: HY024-FHG-3/ HY024-FHG-4


5.6 Connecting Signal Cables

Precautions

When routing communications cables, separate communications cables from power cables to prevent communication from being affected.

COM Port Pin Definitions

Figure 5-18 Communications port



Port	Pin	Definition	Pin	Definition	Description
RS485-1	1	RS485A IN, RS485 differential signal+	2	RS485A OUT, RS485 differential signal+	Used to cascade inverters or connect devices such as the
	3	RS485B IN, RS485 differential signal–	4	RS485B OUT, RS485 differential signal–	SmartLogger.

Port	Pin	Definition	Pin	Definition	Description
PE	5	PE, shield layer grounding	6	PE, shield layer grounding	-
RS485-2	7	RS485A, RS485 differential signal+	8	RS485B, RS485 differential signal-	Connect to the RS485 signal port of devices such as a power meter.

Procedure

Step 1 Connect the RS485 communications cables.

8-10 mm D 4-8 mm 8-11 mm RS485A OUT RS485A IN RS485B OUT RS485B IN RS485A М3 0.5 N·m Θ COM COM _3 N·m IS18H00018

Figure 5-19 Connecting communications cables

Use a plug to block the unused cable hole with the waterproof rubber ring, and then tighten the locking cap.

----End


5.7 (Optional) Installing the Smart Dongle

4G Smart Dongle

NOTICE

- If your Smart Dongle is not configured with a SIM card, you need to prepare one (dimensions: 25 mm x 15 mm; capacity: ≥ 64 KB).
- When installing the SIM card, determine its installation direction based on the silk screen and arrow on the card slot.
- Press the SIM card in place to lock it, indicating that the SIM card is correctly installed.
- When removing the SIM card, push it inward to eject it.
- When reinstalling the enclosure of the Smart Dongle, ensure that the snapfits click into place.


Figure 5-20 Installing the 4G Smart Dongle (SDongleB-06)



IL04H00043


• WLAN-FE Smart Dongle (WLAN communication)

Figure 5-21 Installing the WLAN-FE Smart Dongle (SDongleA-05 for the WLAN communication scenario)



• WLAN-FE Smart Dongle (FE communication)

Figure 5-22 Installing the WLAN-FE Smart Dongle (SDongleA-05 for the FE communication scenario)



NOTICE

Install the network cable before installing the Smart Dongle on the inverter.

MOTE

• For details about how to use the WLAN-FE Smart Dongle SDongleA-05, see **SDongleA-05 Smart Dongle Quick Guide (WLAN-FE)**. You can scan the QR code below to obtain the guide.



For details about how to use the 4G Smart Dongle SDongleB-06, see SDongleB-06
 Smart Dongle Quick Guide (4G). You can scan the QR code below to obtain the guide.



The quick guide is delivered with the Smart Dongle.

6 Checking Before Power-On

Table 6-1 Checklist

No.	Check Item	Acceptance Criteria	
1	Inverter	The inverter is installed correctly and securely.	
2	Smart Dongle	The Smart Dongle is installed correctly and securely.	
3	Cable routing	Cables are routed properly as required by the customer.	
4	Cable tie	Cable ties are evenly distributed and no sharp edge exists.	
5	Grounding	The PE cable is connected correctly, securely, and reliably.	
6	Switch	All DC SWITCH and other switches connected to the inverter are turned off.	
7	Cable connection	The AC output power cable, DC input power cables, and signal cables are connected correctly and securely.	
8	Unused terminal and port	Unused terminals and ports are locked by waterproof glands.	
9	Installation environment	The installation space is proper, and the installation environment is clean and tidy.	

Power-On and Commissioning

DANGER

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

7.1 Powering On the Inverter

Precautions

MARNING

When LED2 is steady green (the inverter is connected to the grid), do not turn on the DC switch. Otherwise, the inverter may be damaged because insulation resistance detection is not performed. You must power off the inverter first, and then turn on the DC switch and restart the inverter.

NOTICE

- Before the equipment is put into operation for the first time, ensure that the parameters are set correctly by professional personnel. Incorrect parameter settings may result in noncompliance with local grid connection requirements and affect the normal operations of the equipment.
- If the DC power supply is connected but the AC power supply is disconnected, the inverter will report the **Shutdown: Fault** fault. The inverter can start properly only after the fault is automatically rectified.
- The DC switches implement automatic disconnection. If cables are reversely connected, PV modules are not properly configured, or an internal fault occurs in the inverter, the DC switches automatically turn off for protection. In this case, rectify the fault as prompted on the app, check that the alarm is cleared, and then turn on the DC switches. Device damage caused by forcible switch-on after the DC switches turn off is not covered by the warranty. (If the DC switches automatically turn off due to an internal fault of the inverter, the Device Fault alarm will be reported. Do not turn on the DC switches again. Perform operations according to the alarm indication.)
- When the system is powered on or running, ensure that there are no obstacles in path of travel of the DC switch handles (for example, the handles are not stuck by cables or mistakenly held by hands) to ensure that the handles can move freely. Otherwise, the DC switches cannot automatically turn off.
- If an inverter has not been running for more than half a year after being mounted, it must be checked and tested by professionals before being put into operation.

Procedure

- **Step 1** At the AC switch between the inverter and the power grid, use a multimeter to measure the grid voltage and ensure that the voltage is within the allowed operating voltage range of the inverter. If the voltage is not in the allowed range, check the circuits.
- Step 2 Turn on the AC switch between the inverter and the power grid.
- **Step 3** Set **DC SWITCH 1** at the bottom of the inverter to **ON**. When you hear a click, the switch is on.
- **Step 4** Check the status of the PV connection indicator. When the PV connection indicator is steady green, set **DC SWITCH 2** to **ON**.
- **Step 5** Observe the LED indicators to check the status of the inverter.

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning	
PV connection indicator	Steady green		At least one PV string is properly connected, and the DC input voltage of the corresponding MPPT circuit is greater than or equal to the minimum startup voltage.	
	Blinking green	fast	If the alarm/maintenance indicator is red, an environmental fault at the DC side of the inverter was generated.	
	Off		The inverter is disconnected from all PV strings, or the DC input voltage of all MPPT circuits is less than the minimum startup voltage.	
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the DC side of the inverter is generated.	
Grid	Steady green		The inverter is in grid-tied mode.	
connection indicator	Blinking green fast		If the alarm/maintenance indicator is red, an environmental fault on the AC side of the inverter was generated.	
	Off		The inverter is not in grid-tied mode.	
	Steady red		If the alarm/maintenance indicator is red, an internal fault on the AC side of the inverter was generated.	
Communicati on indicator	Blinking green fast		The inverter receives communication data normally.	
	Off		The inverter has not received communication data for 10 seconds.	
Alarm/ Maintenance indicator	Alarm	Steady red	 A major alarm was generated. If the PV connection indicator or grid connection indicator is blinking green fast, rectify DC or AC environmental faults as instructed by the SUN2000 app. If neither the PV connection indicator nor the grid connection indicator is blinking green fast, replace components or the inverter as instructed by the SUN2000 app. 	
		Blinking red fast	A minor alarm was generated.	
		Blinking red slowly	A warning alarm was generated.	

Indicator	Status (Blinking Fast: On for 0.2s and Off for 0.2s; Blinking Slowly: On for 1s and Off for 1s)		Meaning
	Local	Steady green	The local maintenance is successful.
	maintenance	Blinking green fast	The local maintenance failed.
		Blinking green slowly	The device is under local maintenance or shut down after receiving a command.

Step 6 (Optional) Observe the Smart Dongle LED indicator to check the status of the Smart Dongle.

• WLAN-FE Smart Dongle

Table 7-1 LED indicators

LED Indicator	Status	Remarks	Description
-	Off	Normal	The Smart Dongle is not secured or is not powered on.
Yellow (steady green and red simultaneousl y)	Steady on		The Smart Dongle is secured and powered on.
Red	Blinking fast (on for 0.2s and then off for 0.2s)		The parameters for accessing the router have not been set.
Red	Steady on	Abnorma l	Replace the Smart Dongle because it has an internal fault.

LED Indicator	Status	Remarks	Description	
Blinking red and green	Blinking slowly (on for 1s and	Abnorma l	Communication with the inverter fails.	
alternatively	then off for 1s)		 Remove and insert the Smart Dongle. 	
			 Check whether the inverter matches the Smart Dongle. 	
			 Connect the Smart Dongle to another inverter. Check whether the Smart Dongle is faulty or the USB port of the inverter is faulty. 	
Green	Blinking slowly	Normal	The device is accessing the	
Green	(on for 0.5s on and off for 0.5s)	Normat	router.	
Green	Steady on		Connection to the management system is successful.	
Green	Blinking fast (on for 0.2s and then off for 0.2s)		The inverter is communicating with the management system through the Smart Dongle.	

• 4G Smart Dongle

Table 7-2 LED indicators

LED Indicator	Status	Remarks	Description
-	Off	Normal	The Smart Dongle is not secured or is not powered on.
Yellow (steady green and red simultaneousl y)	Steady on	Normal	The Smart Dongle is secured and powered on.
Green	The indicator blinks at an interval of 2s, on for 0.1s and then off for 1.9s.	Normal	The dial-up connection is in progress for less than 1 minute.

LED Indicator	Status	Remarks	Description
		Abnorma l	If the duration is longer than 1 minute, the 4G parameter settings are incorrect. Reset the parameters.
	Blinking slowly (on for 1s and then off for 1s)	Normal	The dial-up connection is set up successfully (duration < 30s).
		Abnorma l	If the duration is longer than 30s, the settings of the management system parameters are incorrect. Reset the parameters.
	Steady on	Normal	Connection to the management system is successful.
	Blinking fast (on for 0.2s and then off for 0.2s)		The inverter is communicating with the management system through the Smart Dongle.
Red	Steady on	Abnorma l	Replace the Smart Dongle because it has an internal fault.
	Blinking fast (on for 0.2s and then off for 0.2s)		The Smart Dongle has no SIM card or the SIM card is in poor contact. Check whether the SIM card has been installed or is in good contact. If not, install the SIM card, or remove and insert the SIM card.

LED Indicator	Status	Remarks	Description	
	Blinking slowly (on for 1s and then off for 1s)		The Smart Dongle fails to connect to the management system because the SIM card runs out of the data quota or the signal strength is poor. If the Smart Dongle is reliably connected, check the SIM card signal through the app. If no signal is received or the signal strength is weak, contact the carrier. Check whether the tariff and data quota of the SIM card are normal. If not, top up the SIM card or purchase a data package.	
Blinking red and green alternatively	Blinking slowly (on for 1s and then off for 1s)		Communication with the inverter fails. Remove and insert the Smart Dongle. Check whether the inverter matches the Smart Dongle. Connect the Smart Dongle to another inverter. Check whether the Smart Dongle is faulty or the USB port of the inverter is faulty.	

----End

7.2 Commissioning Methods and Process

The inverter can be commissioned on the SmartLogger WebUI or FusionSolar app.




Figure 7-1 Commissioning process on the SmartLogger WebUI

Figure 7-2 Commissioning process on the FusionSolar app



7.3 Commissioning the SUN2000 (Using the SmartLogger)

7.3.1 Preparations and SmartLogger WebUI Login

For details about preparations and WebUI login, see **SmartLogger3000 User Manual**.

7.3.2 Software Upgrade

For details about software upgrade, see the **SmartLogger3000 User Manual**.

7.3.3 Commissioning Using the Deployment Wizard

Procedure


Step 1 Set basic parameters.

Figure 7-3 Setting basic parameters



- Step 2 Connect to Huawei devices.
 - For RS485 communication, click **Search for Device**. The address is automatically allocated.
 - For MBUS communication, click Choose File or SN List to add the SN of a device. Click Submit to deliver the added device. Then click Search for Device.
- **Step 3** After the device is connected, set the grid code based on the site requirements.






Step 4 Connect to power meters.


Set related parameters by referring to "Setting Meter Parameters" in the SmartLogger3000 User Manual.

Figure 7-5 Connecting to power meters




Step 5 Connect to EMIs.


Figure 7-6 Connecting to EMIs



Step 6 Connect to a Huawei network management system (NMS).

Set related parameters by referring to "Setting Parameters for Connecting to the Management System" (content related to a Huawei NMS) in the SmartLogger3000 User Manual.





Step 7 Connect to a third-party NMS.

Set related parameters by referring to "Setting Parameters for Connecting to the Management System" (content related to a third-party NMS) in the SmartLogger3000 User Manual.


Figure 7-8 Connecting to a third-party NMS



Step 8 Connect to third-party devices.

Set related parameters by referring to "Setting Custom Device Parameters" in the SmartLogger3000 User Manual.

Figure 7-9 Connecting to third-party devices



Step 9 Click **Finish** to complete the configuration.




Figure 7-10 Completing the configuration

----End

7.3.4 Parameters Settings

Choose **Monitoring > Inverter > Running Param.**, set running parameters, and click **Submit**.

Figure 7-11 Setting running parameters



For details about the parameter settings, see the **SmartLogger3000 User Manual**.

7.4 Commissioning the SUN2000 (Using the App)

7.4.1 Downloading the FusionSolar App

For details, see **Downloading and Installing the App** in the *FusionSolar App User Manual*.

7.4.2 Registering an Installer Account

For details, see **Registering the Company's First Installer Account** in the *FusionSolar App User Manual*.

7.4.3 Logging In to or Logging Out of FusionSolar App

For details, see **Logging In to and Logging Out of FusionSolar App** in the *FusionSolar App User Manual*.

7.4.4 Setup Wizard

For details, see **Setup Wizard** in the *FusionSolar App User Manual*.

7.4.5 Commissioning Functions and Features

NOTICE

Only professionals are allowed to set the grid parameters, protection parameters, feature parameters, power adjustment parameters, and grid-tied point control parameters of the inverters. If the grid parameters, protection parameters, and feature parameters are incorrectly set, the inverters may not connect to the power grid. If the power adjustment parameters and grid-tied point control parameters are incorrectly set, the inverters may not connect to the power grid as required. In these cases, the energy yield will be affected.

Choose **Commission Device** and set related device parameters. For details about the parameters, see **FusionSolar App and SUN2000 App Device Commissioning Guide**.

8 System Maintenance

DANGER

 Wear personal protective equipment and use dedicated insulated tools to avoid electric shocks or short circuits.

№ WARNING

 Before performing maintenance, power off the equipment, follow the instructions on the delayed discharge label, and wait for a period of time as specified to ensure that the equipment is not energized.

8.1 Routine Maintenance

To ensure that the inverter can operate properly for a long term, you are advised to perform routine maintenance on it as described in this section.

<u>A</u> CAUTION

- Before cleaning the inverter, connecting cables, and checking the grounding reliability, power off the inverter and ensure that each DC SWITCH on the inverter is set to OFF.
- Do not open the maintenance compartment door on rainy or snowy days. If you need to, take protective measures to prevent rain or snow from entering the maintenance compartment. If protective measures cannot be taken, do not open the maintenance compartment door.

Table 8-1 Maintenance checklist

Check Item	Check Method	Maintenance Method	Maintenance Interval
Alarm	Check alarms on the app, SmartLogger, or management system.	For details, see 9 Alarm Reference. For details about alarm 2062, see 8.6 Locating Insulation Resistance Faults.	Routine maintenance
Cleanness of air intake and exhaust vents	Periodically check whether there is dust or foreign objects at the air intake and exhaust vents.	Power off the inverter and remove dust and foreign objects. If necessary, remove the baffle plate from the air intake vent for cleaning.	Once every 6 to 12 months (or once every 3 to 6 months based on the actual dust conditions in the environment)
Fan	Check whether the fan generates abnormal noise during operation.	Remove foreign objects from the fan. If the abnormal noise persists, replace the fan. For details, see 8.4 Replacing a Fan.	Once every 6 to 12 months
System running status	 Check whether the inverter is damaged or deformed. Check whether the inverter generates abnormal sounds during operation. Check whether all inverter parameters are correctly set during operation. 	Contact the Company's service engineers.	Once every 6 months

Check Item	Check Method	Maintenance Method	Maintenance Interval
Electrical connection	 Check whether cables are disconnected or loose. Check whether cables are damaged, especially whether the cable sheath that contacts a metal surface is damaged. Check whether the sealing plugs of unused DC input terminals fall off. Check whether the unused COM and USB ports are locked by waterproof caps. 	 Power off the inverter and secure loose or disconnected cables. Power off the inverter and replace the damaged cables. Install sealing plugs on unused DC input terminals. Tighten the waterproof caps on the unused COM and USB ports. 	6 months after the first commissioning and once every 6 to 12 months after that
Groundin g reliability	Check whether the ground cables are securely grounded. Use a multimeter to check whether the ground resistance at the inverter ground screws is less than or equal to $4\ \Omega$.	Tighten the screws on both sides of the ground cable and ensure that the resistance meets the requirements.	6 months after the first commissioning and once every 6 to 12 months after that
Vegetatio n around the inverter	Check whether there are weeds around the inverter.	 Perform inspection and weeding as required. Clean the site promptly after weeding. 	Based on the local wilting season

8.2 Shutdown and Power-Off

⚠ WARNING

After the system is powered off, the inverter is still energized and hot, which may cause electric shocks or burns. Therefore, wait for at least 15 minutes and wear PPE before working on the inverter.

- **Step 1** Send a shutdown command on the app, SmartLogger, or management system. For details, see the user manual of the corresponding product.
- **Step 2** Turn off the AC switch between the inverter and the power grid.
- Step 3 Set the two DC SWITCH to OFF.

----End

8.3 Power-Off for Maintenance

Precautions

To prevent personal injury and device damage, use the DC current scale of a clamp meter to measure the PV string current (even if the DC switches have been turned off) before removing PV connectors when troubleshooting or replacing the inverter or PV strings. Ensure that the PV strings have no current, and quickly remove and insert connectors for adjustment.

! CAUTION

- If the inverter is faulty, do not stand in front of it if possible.
- If the LED1 indicator on the inverter is off and each DC switch is set to **OFF**, do not operate any DC switch on the inverter. For details, see **Step 4**.
- Do not operate any DC switch on the inverter before you perform **Step 3** to **Step 5**.
- When the inverter detects a fault, it triggers automatic DC disconnection protection. Do not turn on the DC switches before the fault is rectified.
- If the AC switch between the inverter and the power grid has been turned off automatically, do not turn it on before the fault is rectified.
- Before power-off for maintenance, do not touch the energized components of the inverter. Otherwise, electric shocks or arcs may occur.

Procedure


- **Step 1** Wear proper PPE.
- **Step 2** If the inverter does not shut down due to a fault, send a shutdown command on the app, SmartLogger, or management system. If the inverter has shut down due to a fault, go to the next step.
- **Step 3** Turn off the AC switch between the inverter and the power grid.
- **Step 4** Use a clamp meter to measure the DC current of each PV string input to the inverter.
 - If PV strings have no current, go to the next step.
 - If a PV string has current, wait until the solar irradiance decreases and the PV string has no current at night, and then go to the next step.

- **Step 5** Open the maintenance compartment door, install a support strut, and use a multimeter to check the voltage between the AC terminal block and the ground. Ensure that the AC side of the inverter is powered off.
- **Step 6** Set all DC switches of the inverter to **OFF**. If the DC switches are automatically turned off, go to the next step.
- **Step 7** Wait for 15 minutes and troubleshoot or repair the inverter.

WARNING

- Do not open the panel for maintenance if the inverter is emitting abnormal smell or smoke, or has obvious exceptions.
- If the inverter does not emit abnormal smell or smoke and is intact, repair or restart it based on the alarm handling suggestions. Do not stand in front of the inverter during the restart.

Figure 8-1 Power-off for maintenance



8.4 Replacing a Fan

----End

<u>A</u> CAUTION


- Before replacing a fan, power off the inverter.
- When replacing a fan, use insulated tools and wear PPE.

■ NOTE

If the fan gets stuck when being pulled or pushed, slightly lift it.


Step 1 Remove the screws from the fan tray and store them properly. Pull out the fan tray until the fan tray is flush with the inverter enclosure.

Figure 8-2 Pulling out the fan tray (1)




Step 2 Remove the cable ties shared by the cables, unscrew the connectors, and disconnect the cables.

Figure 8-3 Disconnecting cables




Step 3 Pull out the fan tray.

Figure 8-4 Pulling out the fan tray (2)




- **Step 4** Remove the cable ties from the faulty fan.
 - FAN 1 is faulty.

Figure 8-5 Removing cable ties from FAN 1




• FAN 2 is faulty.

Figure 8-6 Removing cable ties from FAN 2




• FAN 3 is faulty.

Figure 8-7 Removing cable ties from FAN 3




Step 5 Remove the faulty fan (FAN 1 is used as an example).

Figure 8-8 Removing a fan



Step 6 Install a new fan (FAN 1 is used as an example).


Figure 8-9 Installing a fan



Step 7 Bind the fan cables.

• Binding positions for FAN 1


Figure 8-10 Binding the cables of FAN 1



IS06H00113


• Binding positions for FAN 2

Figure 8-11 Binding the cables of FAN 2




• Binding positions for FAN 3

Figure 8-12 Binding the cables of FAN 3




Step 8 Push in the fan tray until the fan baffle plate is flush with the inverter enclosure.

Figure 8-13 Pushing in the fan tray



Step 9 Connect the cables correctly according to the cable labels and bind the cables.

Figure 8-14 Binding cables



Step 10 Push in the fan tray completely and tighten the screws.

Figure 8-15 Reinstalling the fan tray

----End

8.5 Resetting and Turning On the DC Switch

Prerequisites

If string backfeed, string connection in reverse polarity, or internal inverter fault is displayed on the mobile app or remote monitoring system and the DC switch is in the **TRIP** position, the DC switch has been automatically turned off. In this case, rectify the fault based on the alarm handling suggestions before turning on the DC switch.

Procedure

Step 1 Set the DC switch to OFF.

Step 2 Set the DC switch to **ON**.

----End

8.6 Locating Insulation Resistance Faults

If the ground resistance of a PV string connected to the inverter is too low, the inverter generates a **Low insulation resistance** alarm.

The possible causes are as follows:

- A short circuit occurs between the PV array and the ground.
- The ambient air of the PV array is damp and the insulation between the PV array and the ground is poor.

After the **Low insulation resistance** alarm is generated, the inverter automatically triggers insulation resistance fault location. If the fault location is successful, the location information is displayed on the **Alarm Details** screen of the **Low insulation resistance** alarm on the FusionSolar app.

Log in to the FusionSolar app, choose **Alarm > Active alarm**, and choose **Low insulation resistance** to enter the **Alarm Details** screen.

- The positive and negative terminals of a PV string are connected to the PV+ and PVterminals of the inverter, respectively. The 0% position corresponds to the PV- terminal, and the 100% position corresponds to the PV+ terminal. Other percentages indicate that the fault occurs on a PV module or cable in the PV string.
- Possible fault position = Total number of PV modules in a PV string x Percentage of possible short-circuit positions. For example, if a PV string consists of 14 PV modules and the percentage of the possible short-circuit position is 34%, the possible fault position is 4.76 (14 x 34%), indicating that the fault is located near PV module 4, including the adjacent PV modules and their cables. The inverter has a detection precision of ±1 PV module.
- For details about the PV strings corresponding to the MPPT that may be faulty, see
 Table 8-2. The fault can be located only to the MPPT level. Perform the following steps
 to connect the PV strings corresponding to the faulty MPPT to the inverter one by one
 to further locate and rectify the fault.
- When a non-short-circuit fault occurs, the possible short-circuit percentage is not displayed. If the insulation resistance is greater than 0.001 M Ω , the fault is not related to short circuit. Check all PV modules in the faulty PV string one by one to locate and rectify the fault.

Figure 8-16 Definition of the percentage of the short-circuit position




Table 8-2 Mapping between MPPTs and PV strings

MPPTn	PV String	MPPTn	PV String
MPPT1	PV1 to PV3	MPPT2	PV4 to PV6
МРРТ3	PV7 to PV9	MPPT4	PV10 to PV12
MPPT5	PV13 to PV15	МРРТ6	PV16 to PV18
МРРТ7	PV19 to PV21	-	-

Procedure

NOTICE

- In SUN2000MG V600R023C10SPC101 and later versions, insulation resistance detection upon shutdown is supported. If the AC side is not powered on, insulation resistance fault locating is not supported.
- If the irradiance is too strong, the PV string voltage is too high, or only the DC side is powered on but the AC side is not powered on, the insulation resistance fault locating may fail. In this case, the fault locating status on the Alarm Details screen is Conditions not met. Check the PV string voltage on the app, SmartLogger, or the management system. If the voltage is within the normal range, perform the following steps to connect PV strings to the inverter one by one to locate the fault.
- **Step 1** Ensure that the AC connections are normal. Log in to the FusionSolar app, choose **Maintenance** > **Inverter ON/OFF** on the home screen, and send a shutdown command. Set the **DC SWITCH** of the inverter to **OFF**.
- **Step 2** Connect a PV string to the inverter and set the **DC SWITCH** to **ON**. If the inverter status is **Shutdown: Command**, choose **Maintenance** > **Inverter ON/OFF** on the home screen and send a startup command.
- **Step 3** Choose **Alarm** on the home screen, enter the **Active alarm** screen, and check whether a **Low insulation resistance** alarm is reported.
 - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, choose Maintenance > Inverter ON/OFF on the home screen and send a shutdown command. Set the DC SWITCH to OFF. Go to Step 2 and check the other PV strings one by one.
 - If the **Low insulation resistance** alarm is reported 1 minute after the DC side is powered on, check the percentage of possible short-circuit positions on the **Alarm Details** screen and calculate the location of the possibly faulty PV module based on the percentage. Then go to **Step 4**.
- **Step 4** Choose **Maintenance** > **Inverter ON/OFF** on the home screen and send a shutdown command. Set the **DC SWITCH** to **OFF**. Check whether the connectors or DC power cables between the possibly faulty PV modules and adjacent PV modules are damaged.
 - If yes, replace the damaged connectors or DC power cables and then set the DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF on the home screen and send a startup command. View alarm information.
 - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the insulation resistance fault location of the PV string is complete. Choose Maintenance > Inverter ON/OFF on the home screen and send a shutdown command. Set the DC SWITCH to OFF. Go to Step 2 and check the other PV strings one by one. Then, go to Step 7.
 - If the Low insulation resistance alarm is still reported 1 minute after the DC side is powered on, choose Maintenance > Inverter ON/OFF on the

home screen and send a shutdown command. Set the **DC SWITCH** to **OFF** and go to **Step 5**.

- If no, go to **Step 5**.
- Step 5 Disconnect the possibly faulty PV module from the PV string, and use a DC extension cable with MC4 connectors to connect the adjacent PV modules. Set the DC SWITCH to ON. If the inverter status is Shutdown: Command, choose Maintenance > Inverter ON/OFF on the home screen and send a startup command. View alarm information.
 - If no Low insulation resistance alarm is reported 1 minute after the DC side is powered on, the fault occurred on the disconnected PV module. Choose Maintenance > Inverter ON/OFF on the home screen, send a shutdown command, and set the DC SWITCH to OFF. Go to Step 7.
 - If the **Low insulation resistance** alarm is still reported 1 minute after the DC side is powered on, the fault did not occur on the disconnected PV module. Go to **Step 6**.
- Step 6 Choose Maintenance > Inverter ON/OFF on the home screen and send a shutdown command. Set the DC SWITCH to OFF, reconnect the disconnected PV module, and repeat Step 5 to check the adjacent PV modules at the possible fault position.
- **Step 7** Set the **DC SWITCH** to **ON**. If the inverter status is **Shutdown: Command**, choose **Maintenance** > **Inverter ON/OFF** on the home screen and send a startup command.

----End

9 Alarm Reference

For details about alarms, see Inverter Alarm Reference.

10 Technical Specifications

Efficiency

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 0K-MGL0- BR	SUN2000-5 0K-MGL0
Maximum efficiency	≥ 98.6% (380 V), ≥ 98.8% (480 V)	≥ 98.6% (380 V/400 V), ≥ 98.8% (480 V)	≥ 98.0% (220 V)	≥ 98.0% (220 V)	≥ 98.0% (220 V)	≥ 98.0% (220 V)
Efficiency in China	≥ 98.2% (380 V), ≥ 98.4% (480 V)	/	/	/	/	/
Efficiency in Europe	/	≥ 98.3% (380 V), ≥ 98.4% (400 V), ≥ 98.6% (480 V)	≥ 97.5% (220 V)	≥ 97.5% (220 V)	≥ 97.5% (220 V)	≥ 97.5% (220 V)

Input

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 0K-MGL0- BR	SUN2000-5 0K-MGL0
Maximum input voltage ^a	1100 V	1100 V	750 V	750 V	750 V	750 V
Operating voltage range ^b	200–1000 V	200-1000 V	160-750 V	160-750 V	160-750 V	160-750 V

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 OK-MGL0- BR	SUN2000-5 0K-MGL0
Minimum startup voltage	200 V	200 V	160 V	160 V	160 V	160 V
Full-load MPPT voltage range ^c	540-800 V (380 V) 625-850 V (480 V)	540-800 V (380 V/400 V) 625-850 V (480 V)	300-550 V (220 V)	300-550 V (220 V)	300-610 V (220 V)	300-610 V (220 V)
Rated input voltage	600 V (380 V), 720 V (480 V)	600 V (380 V/400 V), 720 V (480 V)	360 V (220 V)	360 V (220 V)	360 V (220 V)	360 V (220 V)
Maximum input current (per MPPT)	48 A	48 A	48 A	48 A	48 A	48 A
Maximum input current (per PV string)	23 A	23 A	23 A	23 A	23 A	23 A
Maximum short-circuit current (per MPPT)	66 A	66 A	66 A	66 A	66 A	66 A
Number of inputs	21	21	21	21	21	21
Number of MPPTs	7	7	7	7	7	7

Note a: The maximum input voltage is the maximum DC input voltage that the inverter can withstand. If the input voltage exceeds this value, the inverter may be damaged.

Note b: If the input voltage is beyond the operating voltage range, the inverter cannot work properly.

Note c: The PV strings connecting to the same MPPT circuit shall use the same model and quantity of PV modules. It is recommended that the PV string voltage be higher than the lower threshold of the full-load MPPT voltage.

Note: To ensure the optimal power generation of the system, the voltage difference between different MPPT circuits shall be less than 126 V.

Output

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 OK-MGL0- BR	SUN2000-5 0K-MGL0
Rated output power	150 kW	150 kW	80 kW	75 kW	50 kW	50 kW
Maximum apparent power	165 kVA	165 kVA	88 kVA	75 kVA	55 kVA	55 kVA
Maximum active power (cosф = 1)	165 kW	165 kW	88 kW	75 kW	55 kW	55 kW
Rated output voltage ^a	Phase voltage/ Line voltage: 220 V/380 V, 277 V/480 V 3W + (N) ^b + PE	Phase voltage/ Line voltage: 220 V/380 V, 230 V/400 V, 277 V/480 V 3W + (N) ^b + PE	Phase voltage/ Line voltage: 127 V/220 V 3W + (N) ^b + PE	Phase voltage/ Line voltage: 127 V/220 V 3W + (N) ^b + PE	Phase voltage/ Line voltage: 127 V/220 V 3W + (N) ^b + PE	Phase voltage/ Line voltage: 127 V/220 V 3W + (N) ^b + PE
Rated output current	227.9 A (380 V) 180.4 A (480 V)	227.9 A (380 V) 216.5 A (400 V) 180.4 A (480 V)	210 A (220 V)	196.9 A (220 V)	131.3 A (220 V)	131.3 A (220 V)
Adapted power grid frequency	50 Hz/60 Hz	50 Hz/60 Hz	50 Hz/60 Hz	50 Hz/60 Hz	50 Hz/60 Hz	50 Hz/60 Hz
Maximum output current	250.7 A (380 V) 198.5 A (480 V)	253.2 A (380 V) 240.5 A (400 V) 200.5 A (480 V)	231 A (220 V)	196.9 A (220 V)	144.4 A (220 V)	144.4 A (220 V)
Power factor	0.8 leading to 0.8 lagging	0.8 leading to 0.8 lagging	0.8 leading to 0.8 lagging	0.8 leading to 0.8 lagging	0.8 leading to 0.8 lagging	0.8 leading to 0.8 lagging

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 0K-MGL0- BR	SUN2000-5 0K-MGL0
Maximum total harmonic distortion (rated power)	< 1% (rated working conditions)	< 1% (rated working conditions)	< 3% (rated working conditions)	< 3% (rated working conditions)	< 3% (rated working conditions)	< 3% (rated working conditions)
Output DC component (DCI)	< 0.5% of the rated current					

Note a: The rated output voltage is determined by **Grid code**, and **Grid code** can be set on the SUN2000 app, SmartLogger, or management system.

Note b: You can determine whether to connect the N wire to the SUN2000 based on the application scenario. In scenarios without N wires, set **Output mode** to **Three-phase, three-wire**. In scenarios with N wires, set **Output mode** to **Three-phase, four-wire**.

Protection

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 OK-MGL0- BR	SUN2000-5 0K-MGL0
Arc-fault circuit interrupter (AFCI)	Optional	Supported	Supported	Supported	Supported	Supported
Built-in PID recovery	Optional	Supported	Supported	Supported	Supported	Supported
Input DC switch	Supported	Supported	Supported	Supported	Supported	Supported
Anti- islanding protection	Supported	Supported	Supported	Supported	Supported	Supported
Output overcurrent protection	Supported	Supported	Supported	Supported	Supported	Supported
Input reverse connection protection	Supported	Supported	Supported	Supported	Supported	Supported

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 OK-MGL0- BR	SUN2000-5 0K-MGL0
PV string fault detection	Supported	Supported	Supported	Supported	Supported	Supported
DC surge protection	Type II	Type II/Type I (optional)	Type II	Type II	Type II	Type II
AC surge protection	Type II	Type II	Type II	Type II	Type II	Type II
Insulation resistance detection	Supported	Supported	Supported	Supported	Supported	Supported
Residual current monitoring unit (RCMU)	Supported	Supported	Supported	Supported	Supported	Supported
Overvoltag e category	PV II/AC III	PV II/AC III	PV II/AC III	PV II/AC III	PV II/AC III	PV II/AC III

Display and Communication

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 0K-MGL0- BR	SUN2000-5 0K-MGL0
Display	LED indicator, USB data cable + App					
RS485	Supported	Supported	Supported	Supported	Supported	Supported
AC MBUS	Supporteda	Supported	Not supported	Not supported	Not supported	Not supported
Optimizer	Not supported	Not supported	Not supported	Not supported	Not supported	Not supported

General Specifications

Item	SUN2000-1 50K-MG0- ZH	SUN2000-1 50K-MG0	SUN2000-8 0K-MGL0	SUN2000-7 5K-MGL0- BR	SUN2000-5 OK-MGL0- BR	SUN2000-5 0K-MGL0
Dimensions (W x H x D)	1000 mm x 710 mm x 395 mm	1000 mm x 710 mm x 395 mm	1000 mm x 710 mm x 395 mm	1000 mm x 710 mm x 395 mm	1000 mm x 710 mm x 395 mm	1000 mm x 710 mm x 395 mm
Net weight (including hanging kits)	98 kg	98 kg	98 kg	98 kg	98 kg	98 kg
Operating ambient temperatur e	-25°C to +60°C	–25°C to +60°C	–25°C to +60°C	–25°C to +60°C	–25°C to +60°C	–25°C to +60°C
Cooling mode	Smart air cooling	Smart air cooling	Smart air cooling	Smart air cooling	Smart air cooling	Smart air cooling
Operating altitude	0-5000 m (derated when the altitude exceeds 4000 m)	0-5000 m (derated when the altitude exceeds 4000 m)	0-5000 m (derated when the altitude exceeds 4000 m)	0-5000 m (derated when the altitude exceeds 4000 m)	0-5000 m (derated when the altitude exceeds 4000 m)	0-5000 m (derated when the altitude exceeds 4000 m)
Relative humidity	0%-100% RH	0%-100% RH	0%-100% RH	0%-100% RH	0%-100% RH	0%-100% RH
Input and output terminals	DC input terminals: CT75A-1T-3 4/ CT75A-1T-3 5 (AVIC	DC input terminals: HH4SFD4T MS/ HH4SMD4T MS				
	JONHON) AC output terminals: waterproof terminal + OT/DT terminal	(Amphenol) AC output terminals: waterproof terminal + OT/DT terminal	(Amphenol) AC output terminals: waterproof terminal + OT/DT terminal	(Amphenol) AC output terminals: waterproof terminal + OT/DT terminal	(Amphenol) AC output terminals: waterproof terminal + OT/DT terminal	(Amphenol) AC output terminals: waterproof terminal + OT/DT terminal
IP rating	IP66	IP66	IP66	IP66	IP66	IP66
Topology	Transformer less	Transformer less	Transformer less	Transformer less	Transformer less	Transformer less

A Grid Codes

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
1	NB/T 32004	China low- voltage power grid	Suppor ted	Suppor ted	-	-	-	-
2	Custo m (50 Hz)	Reserv ed	Suppor ted	Suppor ted	-	-	-	-
3	Custo m (60 Hz)	Reserv ed	Suppor ted	Suppor ted	-	-	1	-
4	CHINA - MV480	China mediu m- voltage standa rd power grid	Suppor ted	-	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
5	CHINA -MV	China mediu m- voltage standa rd power grid	Suppor ted	Suppor ted	-	-	-	-
6	Fuel- Engine -Grid	Genset hybrid power grid	Suppor ted	Suppor ted	-	-	-	-
7	Fuel- Engine - Grid-6 0Hz	Genset hybrid power grid	Suppor ted	Suppor ted	-	-	-	-
8	VDE- AR- N-410 5	Germa ny low- voltage power grid	-	Suppor ted	-	-	-	-
9	UTE C 15-712 -1(A)	France mainla nd power grid	-	Suppor ted	-	-	-	-
10	UTE C 15-712 -1(B)	France island power grid	-	Suppor ted	-	-	-	-
11	UTE C 15-712 -1(C)	France island power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
12	VDE 0126-1 -1-BU	Bulgari a power grid	-	Suppor ted	-	-	-	-
13	VDE 0126-1 -1- GR(A)	Greece mainla nd power grid	-	Suppor ted	-	-	1	-
14	VDE 0126-1 -1- GR(B)	Greece island power grid	-	Suppor ted	-	-	-	-
15	BDEW- MV	Germa ny mediu m- voltage power grid	-	Suppor ted	-	1	1	-
16	G59- Englan d	Englan d 230 V power grid (I > 16 A)	-	Suppor ted	-	-	-	-
17	G59- Scotlan d	Scotlan d 240 V power grid (I > 16 A)	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
18	G83- Englan d	Englan d 230 V power grid (I < 16 A)	-	Suppor ted	-	-	-	-
19	G83- Scotlan d	Scotlan d 240 V power grid (I < 16 A)	-	Suppor ted	-	-	-	-
20	CEI0-2 1	Italy power grid	-	Suppor ted	-	-	-	-
21	EN504 38-CZ	Czech Republ ic power grid	-	Suppor ted	-	-	-	-
22	RD169 9/661	Spain low- voltage power grid	-	Suppor ted	-	-	-	-
23	RD169 9/661- MV480	Spain mediu m- voltage power grid	-	Suppor ted	-	-	-	-
24	EN504 38-NL	Nether lands power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
25	C10/11	Belgiu m power grid	-	Suppor ted	-	-	-	-
26	AS477 7	Austral ia power grid	-	Suppor ted	-	-	-	-
27	IEC617 27	IEC 61727 low- voltage grid- connec tion (50 Hz)	-	Suppor ted	-	1	1	-
28	CEI0-1 6	Italy power grid	-	Suppor ted	-	-	-	-
29	TAI- PEA	Thailan d grid- connec tion standa rd	-	Suppor ted	-	-	-	-
30	TAI- MEA	Thailan d grid- connec tion standa rd	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
31	BDEW- MV480	Germa ny mediu m- voltage standa rd power grid	-	Suppor ted	-	-	-	-
32	Custo m- MV480 (50 Hz)	Reserv ed	-	Suppor ted	-	-	-	-
33	Custo m- MV480 (60 Hz)	Reserv ed	-	Suppor ted	-	-	-	-
34	G59- Englan d- MV480	UK 480 V mediu m- voltage grid connec tion (I > 16 A)	-	Suppor ted	-	-	-	-
35	IEC617 27- MV480	IEC 61727 mediu m- voltage grid- connec tion (50 Hz)	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
36	UTE C 15-712 -1- MV480	France island power grid	-	Suppor ted	-	-	-	-
37	TAI- PEA- MV480	Thailan d mediu m-voltage grid-connec tion (PEA)	-	Suppor ted	-	1	1	-
38	TAI- MEA- MV480	Thailan d mediu m-voltage grid-connec tion (MEA)	-	Suppor ted	-	-	-	-
39	EN504 38-DK- MV480	Denma rk mediu m- voltage grid-connec tion	-	Suppor ted	-	-	-	-
40	EN504 38-TR- MV480	Türkiye mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
41	EN504 38-TR	Türkiye low- voltage power grid	-	Suppor ted	-	-	-	-
42	C11/ C10- MV480	Belgiu m mediu m- voltage power grid	-	Suppor ted	-	-	-	-
43	Philippi nes	Philippi nes low- voltage power grid	-	Suppor ted	-	-	-	-
44	Philippi nes- MV480	Philippi nes mediu m- voltage power grid	-	Suppor ted	-	-	-	-
45	AS477 7- MV480	Austral ia mediu m- voltage power grid	-	Suppor ted	-	-	-	-
46	NRS-0 97-2-1	South Africa standa rd power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
47	NRS-0 97-2-1 - MV480	South Africa mediu m- voltage standa rd power grid	1	Suppor ted	-	-	1	-
48	KOREA	South Korea power grid	-	Suppor ted	-	-	-	-
49	IEC617 27 (60 Hz)	IEC 61727 low- voltage grid- connec tion (60 Hz)	-	Suppor ted	-	-	-	-
50	IEC617 27-60 Hz- MV480	IEC 61727 mediu m- voltage grid- connec tion (60 Hz)	-	Suppor ted	-	-	-	-
51	ANRE	Roman ia low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
52	ANRE- MV480	Roman ia mediu m- voltage power grid	-	Suppor ted	-	-	-	-
53	PO12.3 - MV480	Spain mediu m- voltage power grid	-	Suppor ted	-	-	-	-
54	EN504 38_IE- MV480	Ireland mediu m- voltage power grid	-	Suppor ted	-	-	-	-
55	EN504 38_IE	Ireland low- voltage power grid	-	Suppor ted	-	-	-	-
56	CEI0-1 6- MV480	Italy mediu m- voltage power grid	-	Suppor ted	-	-	-	-
57	PO12.3	Spain low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
58	CEI0-2 1- MV480	Italy mediu m- voltage power grid	-	Suppor ted	-	-	-	-
59	KOREA - MV480	South Korea mediu m- voltage power grid	-	Suppor ted	-	-	-	-
60	Egypt ETEC	Egypt low- voltage power grid	-	Suppor ted	-	-	-	-
61	Egypt ETEC- MV480	Egypt mediu m- voltage power grid	-	Suppor ted	-	-	-	-
62	EN505 49-LV	Ireland power grid	-	Suppor ted	-	-	-	-
63	EN505 49- MV480	Ireland mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
64	Jordan - Transm ission	Jordan low- voltage power grid	-	Suppor ted	-	-	-	-
65	Jordan - Transm ission- MV480	Jordan mediu m- voltage power grid	-	Suppor ted	-	-	-	-
66	NAMIB IA	Namibi a power grid	-	Suppor ted	-	-	-	-
67	ABNT NBR 16149	Brazil power grid	-	Suppor ted	-	-	-	-
68	ABNT NBR 16149- MV480	Brazil mediu m- voltage power grid	-	Suppor ted	-	-	-	-
69	SA_RP Ps	South Africa low- voltage power grid	-	Suppor ted	-	-	-	-
70	SA_RP Ps- MV480	South Africa mediu m- voltage power grid	1	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
71	ZAMBI A	Zambi a low- voltage power grid	-	Suppor ted	-	-	-	-
72	ZAMBI A- MV480	Zambi a mediu m- voltage power grid	-	Suppor ted	-	-	-	-
73	Chile	Chile low- voltage power grid	-	Suppor ted	-	-	-	-
74	Chile- MV480	Chile mediu m- voltage power grid	-	Suppor ted	-	-	-	-
75	Mexico - MV480	Mexico mediu m- voltage power grid	-	Suppor ted	-	-	-	-
76	Malays ian	Malays ia low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
77	Malays ian- MV480	Malays ia mediu m- voltage power grid	1	Suppor ted	-	1	1	1
78	KENYA _ETHI OPIA	Kenya low- voltage power grid and Ethiopi a power grid	-	Suppor ted	-	-	-	1
79	KENYA _ETHI OPIA- MV480	Kenya low- voltage power grid and Ethiopi a mediu m- voltage power grid	-	Suppor ted	-	-	-	-
80	NIGERI A	Nigeria low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
81	NIGERI A- MV480	Nigeria mediu m- voltage power grid	-	Suppor ted	-	-	-	-
82	DUBAI	Dubai low- voltage power grid	-	Suppor ted	-	-	-	-
83	DUBAI - MV480	Dubai mediu m- voltage power grid	-	Suppor ted	-	-	-	-
84	Northe rn Ireland	Northe rn Ireland low-voltage power grid	-	Suppor ted	-	1	1	-
85	Northe rn Ireland - MV480	Northe rn Ireland mediu m-voltage power grid	-	Suppor ted	-	-	-	-
86	Camer oon	Camer oon low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
87	Camer oon- MV480	Camer oon mediu m- voltage power grid	-	Suppor ted	-	-	-	-
88	Jordan - Distrib ution	Jordan power distrib ution networ k low- voltage power grid	-	Suppor ted	-	-	-	-
89	Jordan - Distrib ution- MV480	Jordan power distrib ution networ k mediu m- voltage power grid	-	Suppor ted	-	-	-	-
90	NAMIB IA_MV 480	Namibi a power grid	-	Suppor ted	-	-	-	-
91	LEBAN ON	Lebano n low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
92	LEBAN ON- MV480	Lebano n mediu m- voltage power grid	-	Suppor ted	-	-	-	-
93	ARGEN TINA- MV500	Argenti na mediu m- voltage power grid	-	Suppor ted	-	-	-	-
94	Jordan - Transm ission- HV	Jordan high- voltage power grid	-	Suppor ted	-	-	-	-
95	Jordan - Transm ission- HV480	Jordan high- voltage power grid	-	Suppor ted	-	-	-	-
96	TUNISI A	Tunisia power grid	-	Suppor ted	-	-	-	-
97	TUNISI A- MV480	Tunisia mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
98	AUSTR ALIA- NER	Austral ia NER standa rd power grid	-	Suppor ted	-	-	-	-
99	AUSTR ALIA- NER- MV480	Austral ia NER standa rd power grid	-	Suppor ted	-	-	-	-
10	SAUDI	Saudi Arabia power grid	-	Suppor ted	-	-	-	-
10 1	SAUDI- MV480	Saudi Arabia power grid	-	Suppor ted	-	-	-	-
10 2	Ghana - MV480	Ghana mediu m- voltage power grid	-	Suppor ted	-	-	-	-
10 3	Israel	Israel power grid	-	Suppor ted	-	-	-	-
10 4	Israel- MV480	Israel power grid	-	Suppor ted	-	-	-	-
10 5	Chile- PMGD	Chile PMGD power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
10 6	Chile- PMGD- MV480	Chile PMGD power grid	-	Suppor ted	-	-	-	-
10 7	VDE- AR- N4120 -HV	VDE 4120 standa rd power grid	-	Suppor ted	-	-	-	-
10 8	VDE- AR- N4120 - HV480	VDE 4120 standa rd power grid	-	Suppor ted	-	-	-	-
10 9	Vietna m	Vietna m power grid	-	Suppor ted	-	-	-	-
11 0	Vietna m- MV480	Vietna m power grid	-	Suppor ted	-	-	-	-
11	TAIPO WER	Taiwan Power low- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
11 2	TAIPO WER- MV480	Taiwan Power mediu m- voltage power grid (480 V)	-	Suppor ted	-	-	-	-
11	ARGEN TINA- MV480	Argenti na mediu m- voltage power grid	-	Suppor ted	-	-	-	-
11 4	OMAN	Oman low- voltage power grid	-	Suppor ted	-	-	-	-
11 5	OMAN - MV480	Oman mediu m- voltage power grid	-	Suppor ted	-	-	-	-
11 6	KUWAI T	Kuwait low- voltage power grid	-	Suppor ted	-	-	-	-
11 7	KUWAI T- MV480	Kuwait mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
11 8	BANGL ADESH	Bangla desh low- voltage power grid	-	Suppor ted	-	-	-	-
11 9	BANGL ADESH - MV480	Bangla desh mediu m- voltage power grid	-	Suppor ted	-	-	-	-
12	Chile- Net_Bil ling	Chile Net Billing power grid	-	Suppor ted	-	-	-	-
12	EN504 38-NL- MV480	Nether lands mediu m-voltage power grid	-	Suppor ted	-	-	1	-
12 2	BAHRA IN	Bahrai n low- voltage power grid	-	Suppor ted	-	-	-	-
12	BAHRA IN- MV480	Bahrai n mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
12 4	ARGEN TINA	Argenti na power grid	-	Suppor ted	-	-	-	-
12 5	Mauriti us	Mauriti us power grid	-	Suppor ted	-	-	-	-
12 6	Mauriti us- MV480	Mauriti us mediu m- voltage power grid	-	Suppor ted	-	-	-	-
12 7	EN504 38-SE	Swede n low- voltage power grid	-	Suppor ted	-	-	-	-
12 8	Pakista n	Pakista n power grid	-	Suppor ted	-	-	-	-
12 9	Pakista n- MV480	Pakista n mediu m- voltage power grid	-	Suppor ted	-	-	-	-
13 0	Austria	Austria power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
13	Austria - MV480	Austria mediu m- voltage power grid	-	Suppor ted	-	-	-	-
13 2	G99- TYPEA- LV	UK G99- TYPEA- LV power grid	-	Suppor ted	-	-	-	-
13	G99- TYPEB- LV	UK G99- TYPEB- LV power grid	1	Suppor ted	-	-	-	-
13 4	G99- TYPEB- HV	UK G99- TYPEB- HV power grid	-	Suppor ted	-	-	-	-
13 5	G99- TYPEB- HV- MV480	UK G99- TYPEB- HV mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
13 6	G99- TYPEA- HV	UK G99- TYPEA- HV power grid	-	Suppor ted	-	-	-	-
13 7	EN505 49- MV400	Ireland new standa rd power grid	-	Suppor ted	-	-	1	-
13 8	VDE- AR- N4110	Germa ny mediu m- voltage power grid (230 V)	-	Suppor ted	-	-	-	-
13 9	VDE- AR- N4110 - MV480	Germa ny mediu m- voltage standa rd power grid	-	Suppor ted	-	-	-	-
14 0	NTS	Spain power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
14	NTS- MV480	Spain mediu m- voltage power grid	-	Suppor ted	-	-	-	-
14 2	SINGA PORE	Singap ore low- voltage power grid	-	Suppor ted	-	-	-	-
14	SINGA PORE- MV480	Singap ore mediu m- voltage power grid	-	Suppor ted	-	-	-	-
14	HONG KONG	Hong Kong low- voltage power grid	-	Suppor ted	-	-	-	-
14 5	HONG KONG- MV480	Hong Kong mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
14	C10/11 - MV400	Belgiu m mediu m- voltage power grid	-	Suppor ted	-	-	-	-
14 7	Cambo dia	Cambo dia power grid	-	Suppor ted	-	-	-	-
14 8	Cambo dia- MV480	Cambo dia mediu m- voltage power grid	-	Suppor ted	-	-	-	-
14 9	EN505 49-SE	Swede n low- voltage power grid	-	Suppor ted	-	-	-	-
15 0	GREG0 30	Colom bia low- voltage power grid	-	Suppor ted	-	-	-	-
15 1	GREG0 30- MV440	Colom bia mediu m- voltage power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
15 2	GREG0 30- MV480	Colom bia mediu m- voltage power grid	-	Suppor ted	-	-	-	-
15	PORTU GAL	Portug al low- voltage power grid	-	Suppor ted	-	-	-	-
15 4	PORTU GAL- MV480	Portug al mediu m- voltage power grid	-	Suppor ted	-	-	-	-
15 5	AS477 7_ACT	Austral ia power grid	-	Suppor ted	-	-	-	-
15 6	AS477 7_NSW _ESS	Austral ia power grid	-	Suppor ted	-	-	-	-
15 7	AS477 7_NSW _AG	Austral ia power grid	-	Suppor ted	-	-	-	-
15 8	AS477 7_QLD	Austral ia power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
15 9	AS477 7_SA	Austral ia power grid	-	Suppor ted	-	-	-	-
16 0	AS477 7_VIC	Austral ia power grid	-	Suppor ted	-	-	-	-
16 1	EN505 49-PL	Poland power grid	-	Suppor ted	-	-	-	-
16 2	DANM ARK- EN505 49- DK1- LV230	Denma rk power grid	-	Suppor ted	-	-	-	-
16 3	DANM ARK- EN505 49- DK2- LV230	Denma rk power grid	-	Suppor ted	-	-	-	1
16 4	AUSTR ALIA- AS477 7_A- LV230	Austral ia power grid	-	Suppor ted	-	-	-	-
16 5	AUSTR ALIA- AS477 7_B- LV230	Austral ia power grid	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
16 6	AUSTR ALIA- AS477 7_C- LV230	Austral ia power grid	-	Suppor ted	-	-	-	-
16 7	AUSTR ALIA- AS477 7_NZ- LV230	Austral ia power grid	-	Suppor ted	-	-	-	-
16 8	INVALI D GRID CODE	Invalid grid code	-	Suppor ted	-	-	-	-
16 9	CZECH - EN505 49- LV230	Czech Republ ic power grid	-	Suppor ted	-	-	-	-
17	CZECH - EN505 49- MV480	Czech Republ ic power grid	-	Suppor ted	-	-	-	-
17	ISRAEL - MV400	Israel mediu m- voltage 400 V power grid	-	Suppor ted	-	-	-	-
17 2	ANRE- TYPEB	Roman ia power grid (type B)	-	Suppor ted	-	-	-	-

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
17 3	ANRE- TYPEB- MV480	Roman ia power grid (type B)	-	Suppor ted	-	-	-	-
17 4	AUSTRI A- TYPEB- LV400	Austria power grid	-	Suppor ted	-	-	-	-
17 5	AUSTRI A- TYPEB- LV480	Austria power grid	-	Suppor ted	-	-	-	-
17 6	AUSTRI A- TYPEB- MV400	Austria power grid	-	Suppor ted	-	-	-	-
17 7	AUSTRI A- TYPEB- MV480	Austria power grid	-	Suppor ted	-	-	-	-
17 8	CHINA - GBT29 319- MV480	China power grid	Suppor ted	-				
17 9	CHINA - GBT29 319- LV220	China power grid	Suppor ted	-				
18 0	IEEE 1547- MV480	IEEE 1547- MV480	-	Suppor ted				

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
18	FINLA ND- EN505 49- LV230	Finland power grid	-	Suppor ted				
18 2	TAIPO WER- LV220	Taiwan Power low- voltage power grid	-	-	Suppor ted	-	-	Suppor ted
18 3	Mexico -LV220	Mexico power grid	-	-	Suppor ted	-	-	Suppor ted
18 4	ABNT NBR 16149- LV127	Brazil low- voltage power grid	-	-	-	Suppor ted	Suppor ted	-
18 5	BRAZIL - P140-1 27/220	Brazil P140 power grid	-	-	-	Suppor ted	Suppor ted	-
18 6	Philippi nes- LV220- 50Hz	Philippi nes low- voltage power grid	-	-	Suppor ted	Suppor ted	Suppor ted	Suppor ted
18 7	Philippi nes- LV220- 60Hz	Philippi nes low- voltage power grid	-	-	Suppor ted	-	-	Suppor ted

No.	Grid Code	Descri ption (Count ry/ Region / Standa rd/ Others)	SUN20 00-150 K- MG0- ZH	SUN20 00-150 K-MG0	SUN20 00-80K -MGL0	SUN20 00-75K - MGL0- BR	SUN20 00-50K - MGL0- BR	SUN20 00-50K -MGL0
18 8	SWITZ ERLAN D-NA/ EEA:20 20- LV230	Switzer land power grid	-	Suppor ted	-	-	-	-
18 9	NTS-1 27/220	Spain low- voltage power grid	-	-	-	-	-	Suppor ted
19 0	RD169 9/661- 127/22 0	Spain low- voltage power grid	-	-	-	-	-	Suppor ted
19 1	FRANC E- EN505 49-230	France FD C11-51 9-11	-	Suppor ted	-	-	-	-
19 2	AUSTRI A- TYPEC- MV-40 0	Austria power grid	-	Suppor ted	-	-	-	-
19	AUSTRI A- TYPED - MV-40 0	Austria power grid	-	Suppor ted	-	-	-	-
19 4	AUSTRI A- TYPED - HV-40 0	Austria power grid	-	Suppor ted	-	-	-	-

□ NOTE

The grid codes are subject to change. The listed codes are for reference only.

B Resetting a Password

- **Step 1** Check that the AC and DC sides of the inverter are both powered on, and indicators and → are steady green or blinking slowly for more than 3 minutes.
- **Step 2** Turn off the AC switch, set the DC SWITCH at the bottom of the inverter to OFF, and wait until all LED indicators on the inverter panel turn off.
- **Step 3** After the inverter is powered off, complete the following operations within 4 minutes:
 - 1. Turn on the AC switch and wait for about 90s or until the inverter indicator > blinks.
 - 2. Turn off the AC switch and wait about 30s or until all LED indicators on the inverter panel turn off.
 - 3. Turn on the AC switch and wait for about 90s or until the inverter indicator > blinks.
- **Step 4** Log in to the app and reset the password within 10 minutes. (If no operation is performed within 10 minutes, all parameters of the inverter remain unchanged.)

----End

NOTICE

You are advised to reset the password in the morning or at night when the solar irradiance is low.

C Setting the Current Threshold for Triggering RCD Protection

Function


A residual current device (RCD) detects residual current (that is, leakage current of an electrical system to ground), and automatically disconnects a circuit from its power supply when residual current exceeds the preset threshold.

NOTICE

- If the current threshold for triggering RCD protection is set to a smaller value, the device is more likely to be shut down due to RCD protection. Exercise caution when setting this parameter.
- Adjusting the current threshold for triggering RCD protection may cause the
 device to frequently trigger the protection mechanism. In this case, you can
 increase the threshold to disable the protection mechanism. Exercise caution
 when setting this parameter. If you have any questions, contact the vendor or
 manufacturer.

Procedure

- 1. Log in to the inverter local commissioning screen.
- Choose Settings > Feature parameters > Current Threshold for Triggering RCD Protection. Set Current Threshold for Triggering RCD Protection as required.



Crimping an OT or DT Terminal

Requirements for the OT or DT Terminal

- If a copper cable is used, use copper wiring terminals.
- If a copper-clad aluminum cable is used, use copper wiring terminals.
- If an aluminum alloy cable is used, use copper-aluminum transition wiring terminals, or aluminum wiring terminals along with copper-aluminum transition spacers.

NOTICE

- Do not connect aluminum wiring terminals to the AC terminal block. Otherwise the electrochemical corrosion will occur and affect the reliability of cable connections.
- Comply with the IEC61238-1 requirements when using copper-aluminum transition wiring terminals, or aluminum wiring terminals along with copper-aluminum transition spacers.
- If copper-aluminum transition spacers are used, pay attention to the front and rear sides. Ensure that the aluminum sides of spacers are in contact with aluminum wiring terminals, and copper sides of spacers are in contact with the AC terminal block.




Figure D-1 Requirements for the OT/DT terminal

IS03H00062

Crimping an OT or DT Terminal

NOTICE

- Pay attention not to scratch the core wire when stripping a cable.
- The cavity formed after the conductor crimp strip of the OT or DT terminal is crimped must wrap the core wires completely. The core wires must contact the OT or DT terminal closely.
- Wrap the wire crimping area with a heat shrink tubing or PVC insulation tape. The heat shrink tubing is used as an example.
- When using a heat gun, protect devices from being scorched.




Figure D-2 Crimping an OT terminal


(1) Cable

(2) Core

(3) Heat shrink tubing

- (4) OT terminal
- (5) Hydraulic pliers
- (6) Heat gun

Figure D-3 Crimping a DT terminal



Baud Rate Negotiation

Baud rate negotiation improves the communications rate between the inverter and Dongle, solving or relieving communication congestion.

- During device search in a new plant, the system automatically negotiates the baud rate.
- When replacing or adding an inverter or Smart Dongle at an existing plant, you need to manually deliver local commands on the FusionSolar app to reset the baud rate between devices and negotiate a higher rate.

NOTICE

Baud rate negotiation applies only to RS485 communication in which Dongle networking is used. The inverters networked must be the MG0 or MGL0 series.

Table E-1 Manual baud rate negotiation on the app

Networkin g Mode	Scenario	Operation
Smart Dongle networking	Replacing the Smart Dongle	Use the FusionSolar app to locally scan the QR code to connect to the Dongle.
		 Access the Communication configuration screen, choose RS485 Baud Rate Negotiation, and tap 9600 and Negotiate a higher rate.
	Replacing or adding an inverter	Use the FusionSolar app to locally scan the QR code to connect to the Dongle.
		 Access the Communication configuration screen, choose RS485 Baud Rate Negotiation, and tap 9600 and Negotiate a higher rate.

Troubleshooting

If manual baud rate negotiation fails, refer to the following troubleshooting measures.

Table E-2 Troubleshooting measures

Scenario	Troubleshooting
Negotiat ion	Check whether the device cables are connected properly. If no, connect the device cables correctly.
failed	2. Check whether service operations such as upgrade and log export are performed on the management system. If yes, perform baud rate negotiation again after such operations are complete.
	3. Perform baud rate negotiation again.
	4. When you replace or add an inverter, if you tap Negotiate a higher rate and a message "Negotiation failed. The southbound device does not support the rate." is displayed, it indicates that the device connected to the Dongle does not support baud rate negotiation. In this case, you only need to tap 9600 .
	5. If the fault persists, contact your vendor.

Contact Information

If you have any questions about this product, please contact us.



https://digitalpower.huawei.com

Path: About Us > Contact Us > Service Hotlines

To ensure faster and better services, we kindly request your assistance in providing the following information:

- Model
- Serial number (SN)
- Software version
- Alarm ID or name
- Brief description of the fault symptom

◯ NOTE

EU Representative Information: Huawei Technologies Hungary Kft. Add.: HU-1133 Budapest, Váci út 116-118., 1. Building, 6. floor.

Email: hungary.reception@huawei.com

G Digital Power Customer Service



https://digitalpower.huawei.com/robotchat/

Acronyms and Abbreviations

Α

AFCI arc-fault circuit

interrupter

L

LED light emitting diode

Μ

MBUS monitoring bus

MPP maximum power point

MPPT maximum power point

tracking

Ρ

PID potential induced

degradation

PV photovoltaic

R

RCMU

residual current monitoring unit