



## How to upgrade firmware of Huawei SUN2000 Inverter via fusionsolar App


1. Contact [service@photomate.eu](mailto:service@photomate.eu) to get the latest software file or go to <https://photomate.zendesk.com/hc/en-gb> then select Firmware and choose the device and download and save the .zip file in phone memory.
2. Turn off Mobile data and turn on wifi and connect to Inverter's WLAN.
3. Open Fusion Solar App.
4. Click on three dots on extreme right of App.
5. Click on Device Commissioning.




6. Go to Maintenance.




7. Go to Upgrade device




8. Click on the device for which you want to upgrade firmware



9. You can manually select the firmware version which will be replaced by previous firmware.



10. It will require you to enable the storage permission in settings of your mobile phone.



11. Allow the storage access for FusionSolar App

