How to upgrade firmware of Huawei SUN2000 Inverter via fusionsolar App

1. Contact service@photomate.eu to get the latest software file or go to https://photomate.zendesk.com/hc/en-gb then select Firmware and choose the device and download and save the .zip file in phone memory.

2. Turn off Mobile data and turn on wifi

3. Open Fusion Solar App and log in with username and password

5. Click on Setup wizard → Commission Device → Click Scan → Scan inverter QR code → Log in (Default password *Changeme*)

6.   Go to Maintenance

7.   Go to Upgrade

8. Click on the update for which device you want to upgrade firmware

9. You can manually select the firmware version which will be replaced by previous firmware.

10. It will require you to enable the storage permission in settings of your mobile phone.

11. Allow the storage access for FusionSolar App

10.10 What Should I Do If the Upgrade Package Obtained from an iPhone Cannot Be Selected on the Upgrade Screen?

Cause

In the iOS system, the upgrade package can be selected only from the software installation path. If the upgrade package is not in the software installation path, the upgrade cannot be performed. You need to place the upgrade package in the installation path before the upgrade.

Procedure

Method 1: Share the upgrade package to the FusionSolar app.

Method 2: Save the upgrade package to the specified path (FusionSolar/SolarMate/upGradePatch) of the FusionSolar app.